

TOOLS REQUIRED










2 - People

ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



14	Are you missing anything?	Ch	eck out our Quick Tips!		
	Double-check all parts, hardware and accessories listed are all acccounted for.	han	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then! Prep Time!		
	Should we send any replacements?	Pre			
	Are there any irregularities or flaws in the parts? We can send replacements!		ase review the assembly instructions and all grams prior to assembling.		

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

KING BED





PARTS

1

(2)

(3)

4










HEADBOARD 1pc FOOTBOARD 1pc BUNFEET (HB+FB) 4pcs SLATS 5pcs

(5)







SUPPORT SLATS 10pcs

SIDE RAILS 2pcs

HARDWARE

ASSEMBLY SIDE RAILS













0

OPEN WRENCH 1pc NUTS Ø5/16" 8pcs CURVED WASHER 8pcs


BOLT Ø5/16"x 3" 8pcs



()0000000000>>

WOOD SCREWS Ø8*1 1/4" 10pc


EXPLODED VIEW




packed 3 case

Carton	Disignation	Part		Hardware
	Headboard	# 1		
	Footboard	# 2		
	Bunfeet	# 3		
	Slats	# 4		
	Support Slats	# 5		
	Side rails	#6		#A x 1pc # B x 8pcs
				#C x 8pcs #D x 8pcs
				() # E x 10pcs


1 Part #1 x 1pc Part #3 x 2pcs



2 Part #2 x 1pc Part #3 x 2pcs




Headboard x 1pc
Footboard x 1pc
Part #6 x 2pcs
Hardware #A x 1pc
Hardware #B x 8pcs
Hardware #C x 8pcs
Hardware #D x 8pcs



4 Headboard x 1pc Footboard x 1pc Part #4 x 5pcs Part #5 x 10pcs Part #6 x 2pcs Hardware # E x 10pcs E 6 0 Attach Support Slat (#5) to the Slat (#4) Rotating tightly and attach Slats(#5) to the

Side rails (6) using wood screws (#E).



ASSEMBLY COMPLETED



Please ensure the Furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

- Keep this handy! Please retain this instruction manual and any order-related information for future reference.
- ✓ Lift, don't drag!

 To avoid damage to product please always LIFT the product when transporting of adjusting the placement