

Easy Lift Trim-at-Home Pleated & Cellular Shades by Redi Shade

Use & Care

Use:

Use the middle of bottom rail to raise and lower the shade.

Cleaning:

- General Cleaning-Lightly dust and/or vacuum with upholstery attachment.
- Spot Cleaning- Lightly blot stain using sponge with soap or mild detergent and warm water. Fully open shade and allow to air dry. Entire shade can be cleaned this way if necessary.

Caution:

Full water immersion, dry cleaning, ultrasonic cleaning, spot remover, and strong detergent are not recommended.



Tedi Shade Support: 1-888-608-6611