

MODEL NUMBER	DESCRIPTION
1116VA-30-242-905	SL WRSVL LT GRY 30-IN VTY TZO TOP
1116VA-30-242-901	SL WRSVL LT GRY 30-IN VTY WHT TOP
1116VA-30-242-900	SL WRSVL LT GRY 30-IN VTY MBL TOP
1116VA-30-201-905	SL WRITSVLE WH 30-IN VTY TZO TOP
1116VA-30-201-901	SL WRITSVLE WH 30-IN VTY WHT TOP
1116VA-30-201-900	SL WRITSVLE WH 30-IN VTY MBL TOP

30-IN VANITY WITH TOP

ITEM #1028300; 1028299; 1028298; 1028288; 1028287; 1028286

MODEL #1116VA-30-242-905; 1116VA-30-242-901; 1116VA-30-242-900; 1116VA-30-201-905; 1116VA-30-201-901; 1116VA-30-201-900

AT	TΑ	CH	Y	ΌΙ	JR	RE(CEI	PT	HEF	₹E
----	----	----	---	----	----	-----	-----	----	-----	----


Serial Number	r	Purchase Da	ate

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-866-439-9800, 8 a.m. - 8 p.m., EST, Monday - Sunday.

TABLE OF CONTENTS

Package Contents	3
Hardware Contents	3
Safety Information	3
Preparation	4
Assembly or Installation Instructions	4
Care and Maintenance	10
Warranty	10
Replacement Parts List	11

PART	DESCRIPTION	QUANTITY	CARTON
Α	Vanity	1	Box 2 of 2
В	Тор	1	Box 1 of 2
С	Backsplash	1	DOX 1 01 2
D	Sink	1	
Е	Left Door (preassembled to Vanity (A))	1	Box 2 of 2
F	Right Door (preassembled to Vanity (A))	1	



HARDWARE CONTENTS (NOT SHOWN ACTUAL SIZE)



A

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

Λ

WARNING

• Some steps are more easily handled with 2 adults.

CAUTION

• Use care when assembling the vanity, take your time and follow the assembly instructions closely.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Installation Time: 45 minutes (24 hours for silicone caulk to dry).

Tools Required for Installation (not included): Phillips screwdriver, utility knife or scissors, silicone caulk, power drill with drill bit, measuring tape, level.

INSTALLATION INSTRUCTIONS

Note: Clean area where the vanity (A) will be permanently located prior to beginning installation, ensuring the vanity (A) will not interfere with any water supply and drain lines once mounted.


With two people, carefully place vanity (A) against the wall in its final location. Find and mark locations of wall studs behind the permanent location of vanity (A).
 From inside vanity (A), drill hole through vanity mounting area into wall studs.
 Using mounting hardware (not included) appropriate for your installation site, secure vanity (A) to wall stud. If possible, secure vanity (A) to two wall studs for increased stability.




WARNING

Vanity (A) MUST be secured to the wall.

Note: Use preassembled levelers on feet of vanity (A) to level the item. Twisting the levelers counterclockwise will increase the height of vanity (A), twisting them clockwise will decrease it.



2. Take out the top (B) and backsplash (C) according to the steps indicated by the drawings on the right, and place them face down onto a scratch free surface such as a foam sheet that came in the packaging.




3. Apply silicone caulk (not included) to the top edge of sink (D). With the help of another adult, lower the sink onto the back side of the stone top.


Make sure the sink over-flow hole is facing the front of stone top.

Be sure to align the sink well with the stone top cut out allowing for equal stone overhang on the front, back and sides of the ceramic sink (D).

Note: To install the sink onto the top correctly, ensure that the two "BACK" stamps on the sink and the top are aligned on the same sides. Use the guide lines marked on the sink and bottom side of stone top to assist with sink location.



4. Screw bolts (AA) into the threaded holes of stone top (B).



Hardware Used




Bolt

x 4


5. Lower the sink brackets (BB) over the bolts (AA) and allow to rest on the sink lip. Adjust location of bracket to firmly grasp sink lip. Lower lock washers (DD) over bolts (AA) and secure with nuts (CC). Hand tighten nuts (CC) with included wrench (EE).

DO NOT OVER TIGHTEN!


Tip: Check that the sink placement is well centered front to back and side to side of the stone top cut out before allowing the silicone caulk to dry. If the sink is not centered well unscrew sink clamps, re-adjust the sink position and re-tighten the sink brackets.




Hardware Used



- Helpful tip: it may be easier to install your choice of faucet (not included) before securing the vanity top (B) to vanity base (A).
- 6. To install the stone top with assembled sink to the vanity (A). Apply silicone caulk to the top edge of the wood cabinet. With the help of another adult, gently lower the stone top with assembled sink onto the cabinet. Make sure the stone top is flush with the back side of the wood cabinet and the stone overhang is equal on both sides over the wood cabinet left and right side walls. Remove any excess caulk before allowing to dry.



 Apply silicone caulk (not included) to unpolished side and bottom of backsplash (C). Position backsplash (C) on top (B) and against wall. Clean any excess caulk before allowing to dry.




8. If you need to adjust the doors, do so in the following manner.


To adjust door up or down, loosen screws (a) on both hinges, adjust door, and retighten screws.

To adjust door left or right, turn screws (b) on both hinges, in and out.

To adjust door in or out, loosen screws (c) on both hinges, adjust door, and retighten screws.



9. To remove drawer from vanity base (A), fully extend drawers and locate the plastic levers on left and right sides of the metal glide tracks. Push the plastic levers, on both sides, at the same time, This will disengage the drawer box from the glides. Gently lift up on the drawer to remove it from the glide tracks. Set aside as these will be re-installed.




10. To re-install drawer into vanity (A). Please fully extend metal glide tracks, gently lower and slide drawer box into rear glide catch, then, lower drawer box down to completely rest on extended glides, push plastic levers to lock the drawer box in place.

Note: To Adjust the drawer box height. Please spin the adjustment wheel to the left to raise the drawer box or spin the adjustment wheel to the right to lower the drawer box. You can adjust the left and right side glide heights independently in order to find the drawers best alignment position.

CAUTION

DO NOT force drawer or damage to glide may occur. If drawer does not slide in with ease, remove and try again from the start.

Assembly is now complete. Install desired faucet and drain assemblies (neither included) if not already done at step 6. Per the manufacturers' instructions to complete the installation.



CARE AND MAINTENANCE

- Dust the vanity regularly with a soft, non-lint producing cloth or household dusting product.
- You can clean the vanity with a gentle, non-abrasive household cleaner.
- Make sure to dry the wood immediately with a soft cloth or towel.
- The ceramic sink can be cleaned using standard ceramic cleaning agents available at your local supplier.
- Tips for using touch-up pen (FF): For scratches, stroke in direction of scratch; for worn areas, stroke in direction of wood grain. Rub off excess colorant promptly with a soft cloth.

IMPORTANT


- Shade variations and patterns are an inherent characteristic of stone (e.g. granite, marble, engineered stone). Stone tops will vary from product to product. Use caution placing items such as soap or any fragranced material on the stone surface. Use a soap dish, coaster or similar item to protect the surface if placing any soap or fragranced products on the stone.
- If soap or fragranced products come in contact with the stone top, rinse the surface with water and dry using a soft non-abrasive cloth.
- **WARNING:** Must use cleaning agents safe for stone. Check your cleaning agents use restrictions before using on any stone. Damage to the stone may result. Vanity Manufacturer not responsible for damage caused by improper cleaning agents or soaps used. Warranty will not cover damage caused by the use of improper soaps or cleaning agents.
- **DO NOT** use products to clean the stone top that contain acetone, lemon, vinegar or other acids as these may cause damage to the stone surface.
- Periodically reseal the stone top using an appropriate stone sealer available from your local home store. Follow the manufacturer's directions on how to apply.

WARRANTY

The manufacturer warrants this item against defects in materials and workmanship for a period of one (1) year from the date of original retail purchase. This warranty applies only to the original purchaser. This warranty does not apply to any damage on the product by accident, misuse, or modified, improper installation or by affixing accessories not produced by the manufacturer. The manufacturer will not be held liable for damages caused from cleaners or soaps that etch or stain the stone top. The manufacturer is not accountable whatsoever for product installation during the warranty period. There is no further expressed warranty. The manufacturer shall not be legally responsible for incidental, consequential or special damages arising at or in connection with product use or performance except as may otherwise be accorded by law. The manufacturer disclaims any and all implied warranties.

REPLACEMENT PARTS LIST FOR 1116VA-30-201

For replacement parts, call our customer service department at 1-866-439-9800, 8 a.m. - 8 p.m., EST, Monday - Sunday.






) 9	53		•				
--	--	-----	----	--	---	--	--	--	--

PART	DESCRIPTION	PART#		
	Complete Set 30" Carrara Marble Top	1116VT-30-900		
В	Complete Set 30" Engineered White Top	1116VT-30-901		
	Complete Set 30" Terrazzo Top	1116VT-30-905		
	30" Carrara Marble Backsplash	PU1116BS-30-900		
С	30" Engineered White Backsplash	PU1116BS-30-901		
	30" Terrazzo Backsplash	PU1116BS-30-905		
D	Sink	PU17-19x16-OVAL		
Е	Left Door	- 1116VB-30-201-DOOR SET		
F	Right Door	- 1110VB-30-201-DOOK 3E1		
G	Foot	PU1116-201-FOOT		
Н	Shelf	1116VB-30-201-002		
I	Drawer Front	1116VB-30-201-003		
AA	Bolt			
BB	Sink Bracket			
CC	Nut	GTC-SINK CLIPS		
DD	Lock Washer			
EE	Wrench			
FF	Touch-Up Pen	OF-0010		
GG	Shelf Pin	PU17-SP-002		
HH	Knob (with screw)	PU17-1116-BN		
II	Hinge	PU1116-EU-SC		
JJ	Drawer Glide	PUDTC-14x3-HANDLE		
KK	Leveler	T-1007		

REPLACEMENT PARTS LIST FOR 1116VA-30-242

For replacement parts, call our customer service department at 1-866-439-9800, 8 a.m. - 8 p.m., EST, Monday - Sunday.





PART DESCRIPTION PART # Complete Set 30" Carrara Marble Top 1116VT-30-900 Complete Set 30" Engineered White Top 1116VT-30-901 Complete Set 30" Terrazzo Top 1116VT-30-905 30" Carrara Marble Backsplash PU1116BS-30-900 30" Engineered White Backsplash PU1116BS-30-901 30" Terrazzo Backsplash PU1116BS-30-905 D Sink PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer GTC-SINK CLIPS EE Wrench FT Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE KK Leveler T-1007			~
Complete Set 30" Engineered White Top	PART	DESCRIPTION	PART#
Complete Set 30" Terrazzo Top 1116VT-30-905 30" Carrara Marble Backsplash PU1116BS-30-900 C 30" Engineered White Backsplash PU1116BS-30-901 30" Terrazzo Backsplash PU1116BS-30-905 D Sink PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt Bolt BB Sink Bracket GTC-SINK CLIPS DD Lock Washer GTC-SINK CLIPS EE Wrench Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE		Complete Set 30" Carrara Marble Top	1116VT-30-900
30" Carrara Marble Backsplash PU1116BS-30-900 30" Engineered White Backsplash PU1116BS-30-901 30" Terrazzo Backsplash PU1116BS-30-905 D Sink PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer EE Wrench PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU17-14x3-HANDLE J Drawer Glide PUDTC-14x3-HANDLE C	В	Complete Set 30" Engineered White Top	1116VT-30-901
C 30" Engineered White Backsplash PU1116BS-30-901 30" Terrazzo Backsplash PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt Bolt BB Sink Bracket GTC-SINK CLIPS CC Nut GTC-SINK CLIPS DD Lock Washer EE EE Wrench PU17-SP-002 HH Knob (with screw) PU17-1116-BN HH Knob (with screw) PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE		Complete Set 30" Terrazzo Top	1116VT-30-905
30" Terrazzo Backsplash PU1116BS-30-905 D Sink PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer EE Wrench Wrench PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE		30" Carrara Marble Backsplash	PU1116BS-30-900
D Sink PU17-19x16-OVAL E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt Bolt BB Sink Bracket GTC-SINK CLIPS DD Lock Washer EE EE Wrench FF FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	С	30" Engineered White Backsplash	PU1116BS-30-901
E Left Door 1116VB-30-242-DOOR SET F Right Door PU1116-242-FOOT G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer EE EE Wrench OF-0120R FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE		30" Terrazzo Backsplash	PU1116BS-30-905
F Right Door 1116VB-30-242-DOOR SET G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	D	Sink	PU17-19x16-OVAL
F Right Door G Foot PU1116-242-FOOT H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt Bolt BB Sink Bracket GTC-SINK CLIPS DD Lock Washer EE EE Wrench OF-0120R FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	Ε	Left Door	1116VB 30 242 DOOP SET
H Shelf 1116VB-30-242-002 I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket CC Nut GTC-SINK CLIPS DD Lock Washer EE EE Wrench OF-0120R FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	F	Right Door	1110VB-30-242-DOOK 3E1
I Drawer Front 1116VB-30-242-003 AA Bolt BB Sink Bracket GTC-SINK CLIPS CC Nut GTC-SINK CLIPS GTC-SINK CLIPS DD Lock Washer EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 PHH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	G	Foot	PU1116-242-FOOT
AA Bolt BB Sink Bracket CC Nut DD Lock Washer EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	Н	Shelf	1116VB-30-242-002
BB Sink Bracket GTC-SINK CLIPS CC Nut GTC-SINK CLIPS DD Lock Washer EE EE Wrench OF-0120R FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	I	Drawer Front	1116VB-30-242-003
CC Nut GTC-SINK CLIPS DD Lock Washer EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	AA	Bolt	
DD Lock Washer EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	BB	Sink Bracket	
EE Wrench FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	CC	Nut	GTC-SINK CLIPS
FF Touch-Up Pen OF-0120R GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	DD	Lock Washer	
GG Shelf Pin PU17-SP-002 HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	EE	Wrench	
HH Knob (with screw) PU17-1116-BN II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	FF	Touch-Up Pen	OF-0120R
II Hinge PU1116-EU-SC JJ Drawer Glide PUDTC-14x3-HANDLE	GG	Shelf Pin	PU17-SP-002
JJ Drawer Glide PUDTC-14x3-HANDLE	HH	Knob (with screw)	PU17-1116-BN
	II	Hinge	PU1116-EU-SC
KK Leveler T-1007	JJ	Drawer Glide	PUDTC-14x3-HANDLE
	KK	Leveler	T-1007