

Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance







-   ● Not for commercial use. For residential use only .
-   ● Do not put hot items directly on furniture surface
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-   ● Children should not climb or jump on the furniture.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-   ● Stains may be removed with mild soap solution and damp cloth.
-   ● Keep away from sources of ignition.
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

Please look in the Seat Panel for hardware packs.



Club Chair



Parts List


Label	Picture	Description	QTY
A		Seat Panel	1
B		Left Leg Panel	1
C		Right Leg Panel	1
D		Backrest panel	1
E		Seat Cushion	1
F		Back Cushion	1

Hardware:


No.	Picture	Description	QTY
①		Bolt (M6x40mm)	3
②		Bolt (M6x65mm)	3
③		Bolt (M8x45mm)	9
④		Flat Washer (M6/16 x 5mm)	3
⑤		Allen Wrench	1

Assembly Preparation


Before Beginning Assembly:




A




D




E



B



C



F

①  x 3

②  x 3

③  x 9

④  x 3

⑤  x 1



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

OVERVIEW




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, non-marring surface.

Step 2




With the help of your adult partner, attach the Seat Panel (A) to the Left Leg Panel (B) by using Bolts (③) with Allen Wrench (⑤) as shown in the picture above.
Do not fully tighten the Bolts.

Step 3



With the help of your adult partner, attach the Right Leg Panel (C) to the Seat Panel (A) of the assembled part in Step 2 as shown above.
Flip the product to the opposite side, then secure the Right Leg Panel (C) to the Seat Panel (A) by using Bolts (③) with Allen Wrench (⑤) as shown in the picture above.
Do not fully tighten the Bolts.


Step 4



With the help of your adult partner, attach the Backrest Panel (D) to the Seat Panel (A) by using Bolts (①) with Allen Wrench (⑤) as shown in the picture above.

Do not fully tighten the Bolts.

Step 5




With the help of your adult partner, stand the Chair up.

Then secure the Backrest Panel (D) to the Left Leg Panel (B) and Right Leg Panel (C) by using Bolts (②) and Flat Washer (④) with Allen Wrench (⑤) as shown in the picture above.

Do not fully tighten the Bolts.

Step 6



Inspect it and make sure all parts are adequately connected.

Gently and gracefully, sit onto the Chair.

This will help to align all the parts at all joint areas.

Then get off the Chair and in a sequential manner, gradually tighten all Bolts at all joints until evenly connected.

If there are still wobbles, loosen the Bolts, Screws and execute this same process.

Place the Seat Cushion (E) by affix the Magic Tape Straps on the Seat Panel (A) and then place the Back Cushion (F) onto the Seat Cushion (E) as shown above.

Adjust Pre-installed Leveler height for balance as shown above.

WARNING!! IF CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.