

Size: 9*10.8cm

IQsound®

Smart True Wirelss Earbuds

with Digital LCD Touchscreen
and Smart APP Control



Model No.: IQ-341ANC

Please read carefully this manual before operating the device.

Un-boxing the device


- 2 x Wireless Earbuds & Silicone Tips
- 1 x Charging Case
- 1 x Type-C Cable
- 1 x User Manual

Specifications

Bluetooth Version: V5.3
Speaker Diameter: 13 mm
Speaker Power Output: 3 mW
Speaker Sensitivity: 112dB ± 3dB
Speaker Impedance: 32 Ω
Battery Capacity: 3.7V, 300mAh
Frequency Response: 20Hz-20KHz
Bluetooth Connecting Range: 10m
APP: "FereFit" Smart APP

BATTERY CASE:
Capacity: 300 mAh
Charging Port: USB Type-C
Earbud Battery: 30 mAh
Playing Time:
Up to 5H + 15H with charging case
Charging Time: approx. 1H

Introduction



How to connect

Pairing the Earbuds with your mobile device

- The earbuds will turn on when the Charging case cover is opened, they will pair with each other automatically within 2 seconds. Take out both earbuds from the Charging Case.
- Activate the Bluetooth function on your device and search for nearby devices.
- Select "IQ-341ANC EARBUDS" from the list to connect with the TWS earbuds.
- Once paired successfully, you would hear a beep.
- Your device is now connected and you can play music or take calls with your IQsound TWS Earbuds.

AUTO CONNECTION

- After you pair the earbuds to your device for the first time, the earbuds will pair your device automatically once they're taken out of charging case.
- Note: When the abnormal operation of the user causes the device to only connect to a single earbud or cannot search for the Bluetooth name, please put the dual earbuds back into the charging case, delete the pairing record in the device, then turn off the device Bluetooth. Then reconnect your device with the earbuds in standard way.

How to use the MFB Touch Button

Music	Play/Pause	Click the MFB button
	Next song	Double click the R-MFB key
	Previous song	Double click the L-MFB key
	Increase/decrease volume	Slide MFB keys up/down
	Noise reduction/transparency/and off mode	Long press the R-MFB button for 3 seconds
	Activate Siri/Google Assistant	Long press the L-MFB button for 3 seconds
	Auto Play/Pause	Wearing/Removing earbuds (Turn it on in the Settings of the charging case)

Earbuds	Power On	Charging case power on/ automatically turns on when opened
	Power Off	Automatically shut down after 5 minute without Bluetooth connection
	Auto Pairing	Automatic pairing for out of the charging case
Charging Case	Manual Pairing	Open the lid and press and hold the Power button of charging case for 3 seconds
	Power On	Long press the Power button for 3 seconds
	Power Off	Enter the "Settings - System menu - Power off" interface to turn it off
	On/Off Screen	Click the Power button Double tap the screen to wake up
	Return to Home	Click the Power button



- Click 1 times: Play/pause/answer/hang up
- Click 2 times: Previous song
- Long press for 3 seconds: Activate Siri/Google Assistant
- Slide up and down: Increase/decrease volume
- Click 1 times: Play/pause/answer/hang up
- Click 2 times: Next song
- Long press for 3 seconds: Noise reduction/transparency/off mode
- Slide up and down: Increase/decrease volume

Tips: It can also change the L/R earbud operation on the Charging Case or APP (Home - Key settings).

How to Charge the Earbuds

- Check the battery life on the Charging case screen. Once the earbuds reach low battery, Put both earbuds into the charging case, the earbuds will now automatically start charging.

How to Charge the Charging Case

- Plug the Type-C end of the included cable into the charging case.
- Plug the USB-A side of the included cable into a suitable USB charger on other power source or any computer or other 5V but current do not exceed 2A output charger.
- When charging the charging case, the screen displays the charging interface.



How to use Smart APP

- Download the "FereFit" Smart App on your mobile phone. You can search "FereFit" Smart App in your APP store or scan below QR Code.




Connect with APP and Charging Case - Method 1

- Make sure the APP is not in the background, open the cover of the charging case, turn on the device Bluetooth, and select "IQ-341ANC EARBUDS" to connect the earbuds.
- Click on the APP and wait for the pairing popup, and click to bind the device for pairing.



Connect with APP and Charging Case - Method 2

- When the charging case is in the power-on state, Open the APP and click "device" - search device" and find "IQ-341ANC CASE" for pairing. (The APP interface may be different for different phone systems.)



Home icon of Charging Case Description

- White: Bluetooth connected
- Red: Bluetooth disconnected
- Left earbud in charging case (charging) and battery level display
- Right earbud out of the case and battery level indicator




- Earbuds connected to charging case
- Earbuds disconnected to charging case
- Earbuds and Phone are connected to charging case

Tips: If the earbuds are disconnected from the case, please put it in the case, or press and hold the power button of the case for 3 seconds.

Smart Screen Display Functions

- Power on for the first time: Press and hold the power button for 3 seconds to power on, select the language.




- Press and hold the dial for 3 seconds Switch more themes.



Tips: It can also set more themes in the APP. ("device-dial center")

3. Other Functions(Swipe down/left/right on the Home to find more functions)




Tips: For more functions, please find the screen of the charging case.

APP Functions


1. EQ settings:

- There are default, pop, rock, jazz, classical, folk and custom.




2. Key setting:

- You can set the single click, double click, triple click, and long press functions of the left/right earbuds. Resetting the earbuds and charging case will return to the default mode (Set in charging case screen: Settings-System menu-Factory reset)



3. Device

- It has functions such as finding the Charging case, remote photo taking, address book synchronization, message push, Set a theme in the dial center etc.



4. Movement track

- Sports track with GPS



Disconnection and Connecting to another Device:

- If you want to use the IQsound (IQ-341ANC CASE) on another mobile phone, first you need to disconnect to the current device and connected "FereFit" Smart App.
- Click the device screen on the APP, and click unbind, and swipe left to select delete device.
- Follow the below process: device > unbind > Slide left > unbind > disconnect , this will disconnect your device with "FereFit" Smart App. And search for IQsound (IQ-341ANC CASE) in new mobile device.

Tips: If the charging case is connected to the device Bluetooth, please disconnect the Bluetooth together or more than 10-15 meters away from the original connected phone.

Cleaning

- Do not expose the earbuds to excessive amounts of liquid, moisture or humidity to avoid the product's internal circuit of being affected.
- Do not use abrasive cleaning solvents to clean the device.
- Only clean the product with a slightly damp cloth and mild washing-up liquid.

Attention/Danger!

- Do not listen to high volume sound for a prolonged time to avoid hearing damage. Set the volume to a safe level. The louder the volume, the higher the damage.
- Only use a charger with the right output, the output can be found on the rating label of the earbuds. In case of any doubts don't use the charger!

Safety Precaution

- Do not expose earbuds to extreme temperatures.
- Do not attempt to modify this product. Doing so will void the warranty and could result in personal injury or product failure.
- Do not immerse in water, such as while taking a bath or washing your face, otherwise sound deterioration or failures may result.
- Wipe the earbuds and sleeves with mild antiseptic to avoid infections. Do not use alcohol-based disinfectants.
- The cable connectors to the earbuds may collect debris or other deposit that can affect audio quality. If this happens, disconnect the cables and clean them using a dry cotton swab.

- Set the volume level of the audio device to minimum, and then after connecting the earbuds, adjust the volume gradually. Sudden exposure to loud noises could cause hearing damage.
- Stop using the earbuds immediately if they are causing great discomfort, irritation, rash, discharge, or any other uncomfortable reaction.
- Do not use when a failure to hear your surroundings could be dangerous, such as while driving, or when biking, walking, or jogging where traffic is present and accidents could occur.

DISPOSAL

- Waste electrical production should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Warranty

Basic Warranty Statement
Supersonic Inc. ("Supersonic") warrants this product to the original purchaser ONLY, to be free from defects in materials and workmanship under normal use, for ninety (90) DAYS from the date of original purchase. Proof of purchase (receipt) required. Please visit <http://www.supersonicinc.com/warranty> for additional information.

Garantía

Declaración básica de garantía
Supersonic Inc. ("Supersonic") garantiza este producto al comprador original SOLAMENTE, para estar libre de defectos en materiales y mano de obra bajo uso normal, por noventa (90) DÍAS a partir de la fecha de compra original. Se requiere una prueba de compra (recibo). Visite <http://www.supersonicinc.com/warranty> para obtener información adicional.