
















ASSEMBLY INSTRUCTION

LANGET LOUNGE SET BLACK





WF191355AAB, WF191356AABE, WF191357AAB

Part List & Hardware

A  (3pcs)	B  (3pcs)	C  (2pcs)	D  (2pcs)
E  (2pcs)	F  (2pcs)	G  (5pcs)	H  (1pc)
J  (1pc)	K  (1pc)	L  (1pc)	M  (2pcs)
N  (1pc)	O  (1pc)	1  M 6 x 25 mm (52pcs)	2  M 6 x 110 mm (6pcs)
3  Ø 6 x 14 x 1 (58pcs)	4  (10pcs)	5  4 x 60 (3pcs)	

STEP 1:

x 2





① *2

③ *2

STEP 2:

x 2





② *2

③ *2

STEP 3:

x 2





① *6

③ *6

STEP 4:

x 2





① *4

③ *4

STEP 5:


x 2



④ *2


STEP 6:

x 2




STEP 7:

x 2




STEP 8:



① *2

③ *2


STEP 9:



② *2

③ *2



STEP 10:



① *8

③ *8



STEP 11:



① *6


③ *6

STEP 12:




④ *2



STEP 13:



STEP 14:





STEP 15:



① *4

③ *4



STEP 16:



① *8

③ *8

STEP 17:



④ *2

STEP 18:

