



# Outdoor Light Guideline



## Front Door: Single Side

Position the light fixture on the same side as the doorknob in order to see your visitors' faces when opening the door at night. Mount the center of the fixture at eye level, or 60"- 65" from the ground.



### Front Door: Both Sides

When mounting exterior wall lights beside a door, position the fixtures at eye level, or 60"- 65" from the ground. For the best spread of light, the fixture should measure at least 1/4 the height of the door..