


ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

Dining Table



ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION







ITEM NO.N715P297483



ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

Part List

Ⓐ 	Ⓑ 
TABLE TOP (1 pc)	UPPER CROSSBAR (2 pcs)
Ⓒ 	Ⓓ 
DECORATIVE SIDE BEAM (4 pcs)	CENTRAL LEG SUPPORT FRAME (1 pc)
Ⓔ 	Ⓕ 
DECORATIVE SIDE BEAM (2 pcs)	UPPER CROSSBAR (2 pcs)
Ⓙ 	
LOWER CENTER SUPPORT BLOCK (1 pc)	

ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

Hardware List


①



Ø 5/16" x 40 mm

BOLT (18 pcs)

②



Ø 5/16" x 50 mm

BOLT (16 pcs)

③



Ø5/16" x 13 mm

LOCK WASHER (34 pcs)

④



Ø5/16"x19x2 mm

FLAT WASHER (12 pcs)


⑤



4 mm

ALLEN KEY (1 pc)

⑥




Ø10 x 30 mm

WOOD DOWEL (2 pcs)

ASSEMBLY INSTRUCTION


ITEM NO.N715P297483

STEP 1:



2	3	5
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
② x 4	③ x 4	⑤ x 1

STEP 2:




2	3	5	6
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm	WOOD DOWEL Ø 10 x 30mm
			
② x 4	③ x 4	⑤ x 1	⑥ x 2

ASSEMBLY INSTRUCTION


ITEM NO.N715P297483

STEP 3:



1	3	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
① x 6	③ x 6	⑤ x 1

STEP 4:




2	3	5
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
② x 8	③ x 8	⑤ x 1

ASSEMBLY INSTRUCTION


ITEM NO.N715P297483

STEP 5:



1	3	4	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
① x 4	③ x 4	④ x 4	⑤ x 1

STEP 6:




1	3	4	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
① x 8	③ x 8	④ x 8	⑤ x 1



ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

STEP 7:




STEP 8:





ASSEMBLY INSTRUCTION

ITEM NO.N715P297483

STEP 9:





STEP 10:



ASSEMBLY INSTRUCTION

ITEM NO.N715P297483


STEP 11:



ASSEMBLY INSTRUCTION

ITEM NO.N715P297483


COMPLETE



ASSEMBLY INSTRUCTION

ITEM NO.N715P297488

Dining Chair



ASSEMBLY INSTRUCTION

ITEM NO.N715P297488

Please read these instructions fully before starting assembly:




1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P297488




ASSEMBLY INSTRUCTION

ITEM NO.N715P297488


Part List For 4

A




BACK CHAIR (4pcs)

B



SEAT CHAIR (4pcs)

C




LEG FRONT (8pcs)

ASSEMBLY INSTRUCTION

ITEM NO.N715P297488

Hardware List For 4


①



Ø1/4 " x 40mm

BOLT (8pcs)


②



Ø1/4 " x 55mm

BOLT (16pcs)


③



Ø1/4 " x 75mm

BOLT (16pcs)


④



Ø5/16 " x 13mm

LOCK WASHER (40pcs)

⑤



Ø5/16 " x 19 x 2 mm

FLAT WASHER (40pcs)

⑥




4 mm

ALLEN KEY (1pc)

ASSEMBLY INSTRUCTION


ITEM NO.N715P297488

STEP 1 :



1	3	4	5	6
BOLT Ø 1/4 " x 40mm	BOLT Ø 1/4 " x 75mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
				
① x 2	③ x 4	④ x 6	⑤ x 6	⑥ x 1

STEP 2 :



2	4	5	6
BOLT Ø 1/4 " x 55 mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
② x 4	④ x 4	⑤ x 4	⑥ x 1

ASSEMBLY INSTRUCTION

ITEM NO.N715P297488

COMPLETE

