









USE AND CARE MANUAL

TABLE LAMP SET OF 2
Model number: 21241-W



Hardware (Parts are not to scale)

H1 Finial (Pre-assembled to harp (H2)) 2 pcs 	H2 Harp 2 pcs 	H3 Shade panel 2 pcs 	H4 Top ring 2 pcs 
H5 Bottom ring 2 pcs 	H6 Socket assembly (connecting to fixture body (A)) 2 pcs 	H7 9.5W LED Bulb 2 pcs 	

**THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND
KEEP FOR FUTURE REFERENCE.**

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids.
 - Never cover the lamp with any object including cloth or paper as this is a fire hazard.
 - Do not handle the bulb immediately after the light is turned off as it will be hot.
 - This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
-

PREPARATION

- Before beginning assembly, installation or operation of product, make sure all parts are present. Compare parts with package contents list and diagram on the previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.
-

ASSEMBLY


SHADE ASSEMBLY

1 Assembling the shade

- Place the shade panel (H3) and top ring (H4) and bottom ring (H5) from the box.
- Attach the top ring (H4) and the bottom ring (H5) to clips on the shade panel (H3) securely into the clips.
- Attach the shade panel (H3) together by velcro.
- Repeat this step for the second shade.

NOTE: Push and pull the shade panel (H3) to be tight before attaching it together by velcro.

The clips will not fit where the ring and the stretchers meet. The big ring of the top ring is towards the outside of the shade assembly.




ASSEMBLY (continued)

LAMP ASSEMBLY


1 Assembling the socket assembly

- Properly fold the wire as per the method as shown in the below diagram, and insert the folded wire into tube of the socket assembly (H6).
- Tighten the socket assembly (H6) onto the fixture body (A).



2 Installing the harp


- Insert the harp (H2) prongs into the saddle of the socket assembly (H6) and slide the retaining covers over joints to secure the harp.



3 Installing the light bulb

- Install the light bulb (H7) into the socket. Use one **MAX 16 W medium base (E26) self-ballasted LED bulb (9.5 W medium base (E26) self-ballasted LED bulb included)**.


NOTE: You can also use one **MAX 100W medium base (E26) type "A" bulb**. Do not exceed the recommended wattage.



4 Installing the shade

- Unscrew the finial (H1) from the harp (H2).
- Place the shade assembly onto the harp (H2) and secure with the finial (H1).

NOTE: Grasp the finial (H1) to adjust the shade assembly to level if shade is skewed.




NOTE: Grasp the finial (H1) to adjust the shade assembly to level if shade is skewed.

ASSEMBLY (continued)

LAMP ASSEMBLY


5 Assembling the second lamp

- Repeat steps 1 - 4 for the second lamp.




6 Using the table lamp

- Plug into the wall outlet. turn on the switch and enjoy.



7 Using the USB port

- On the side of the base, there is a built in Dual USB (type A port and one type C port) for you to connect a charging cable (not included) (powers phones, tablets & more).
- The built-in USB port type A and type C rating: **5Vdc, 2.1A.**



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
 - a) Check whether the bulb was burned out.
 - b) Ensure the power supply is turned on.
 - c) Ensure the cord is plugged into an outlet.
 - d) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
 - a) Check for crossed wires, ensure wiring is correct.