

CM351300TX

Counter Height Universal Table –

Espresso

Assembly Instructions



Southern
ENTERPRISES


For assistance with assembly, contact:

Southern Enterprises Inc.

customer service 1-800-633-5096

service@seidal.com

www.seidal.com
























Counter Height Universal Table – Espresso

Parts List

Please check packaging for all parts and hardware before discarding. Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated. Call customer service if hardware is missing.

Before beginning assembly, carefully study the diagrams below and sort your hardware according to the pictures. Using the incorrect hardware will cause damage.


A <p>Quantity of 3</p>  <p>cam bolt</p>	B <p>Quantity of 4</p>  <p>wood dowel</p>	C <p>Quantity of 3</p>  <p>cam lock</p>
D <p>Quantity of 14</p>  <p>nut</p>	E <p>Quantity of 14</p>  <p>bolt: dia 1/4" x 2" L</p>	F <p>Quantity of 3</p>  <p>hinge for top</p>
G <p>Quantity of 4</p>  <p>hinge for leg</p>	H <p>Quantity of 42</p>  <p>short screw</p>	I <p>Quantity of 3</p>  <p>long screw</p>
J <p>Quantity of 14</p>  <p>sticker cover</p>	K <p>Quantity of 6</p>  <p>leveler</p>	L <p>Quantity of 1</p>  <p>allen wrench</p>

1  top panel-A quantity of 1	2  top panel-B quantity of 1	3  back rail quantity of 1
4  front rail quantity of 2	5  under rail quantity of 2	6  outside left frame quantity of 1
7  inside left frame quantity of 2	8  outside right frame quantity of 2	9  inside right frame quantity of 1

Care and cleaning instructions:
Before use, wipe with a clean, dry cloth.
Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please
Call customer service at 1-800-633-5096

Assembly Tool Required
No.2 Phillips Screwdriver (Not Included)



Counter Height Universal Table – Espresso

Assembly Instructions




Figure 1

Tip: Wood may scratch easily, Be careful when assembling.


Insert nut (D) into holes on backside of rails (3), (4), and (5).

Insert bolt (E) into holes on inside left frame (7) and inside right frame (9). Attach three rails (3), (4), and (5) to inside left frame (7) and inside right frame (9) by bolt (E) into corresponding holes until three rails (3, 4, and 5) and frames (7) and (9) meet.

Tighten bolt (E) by using allen wrench (L) as shown.

Tip: Make sure nut (D) is inserted with grooves for screwdriver visible.

Cover bolt holes with sticker cover (J).




Insert cam lock (C) into holes on pre-assembled unit.

Screw cam bolt (A) into holes on backside of top panel–A (1). Attach top panel–A (1) to pre-assembled unit by inserting wood dowel (B) and cam bolt (A) into corresponding holes until top panel–A (1) and pre-assembled unit meet.

Tighten by rotating cam lock (C) clockwise with phillips screwdriver.


Insert long screw (I) into predrilled holes on front rail (4) and then tighten screw using phillips screwdriver as shown.



Attach hinge for leg (G) to outside left frame (6) and inside left frame (7) with short screw (H). Tighten short screw (H) by using phillips screwdriver as shown.

Repeat assembly for outside right frame (8) and inside right frame (9).

Figure 3



Attach hinge for top (F) to top panel-A (1) and top panel-B (2) using short screw (H) and tighten screw using phillips screwdriver as shown.

Figure 4




Figure 5

Attach leveler (K) to pre-assembled unit by hand as shown.





Figure 6

Turn the table over.

Adjust the leveler (K) by hand if the table is not level.


Now your counter height universal table is ready to use.



To fold the table, first, turn top panel-B over onto top panel-A. Then, turn the two outside frames over onto the inside frames as shown.

Reverse the steps in order to convert into a dining table.

Figure 7



The table is folded.

Adjust the leveler (K) by hand if the table is not level.

Figure 8

Parts Replacement Form

Customer Information

Name _____

Address _____

City/State/Zip Code _____

Phone Number _____

Please indicate where you purchased this item: Store/Website/Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed
----------	--------------	-------------------	-----------------

_____	_____	_____	_____
-------	-------	-------	-------

_____	_____	_____	_____
-------	-------	-------	-------

_____	_____	_____	_____
-------	-------	-------	-------

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am – 4pm Mon-Fri Central time if you have product issues or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Southern
ENTERPRISES

Customer Service 1-800-633-5096

service@seidal.com

Southern Enterprises, Inc.

600 Freeport Parkway, Suite 200

Coppell, Texas 75019