

Liv EZ™ Installation Checklist

ELKAY®


Every installation site is different. To ensure a smooth installation of the Liv EZ™ water dispenser, please review this checklist and ensure the wall and surrounding space is properly prepped. This checklist is not intended to replace the installation instructions shipped with the product.



Delivery

Liv EZ shipping weight: 29 lbs.

Liv EZ chiller shipping weight: 78 lbs.



Space Requirements

Which product do you plan to install?



Water dispenser

Dimensions: 4-9/16" x 16-3/4" x 20-1/2"



Remote Chiller (ERS11Y)

Dimensions: 22"L x 19-1/2"W x 7-7/8"D

- Chilling capacity: 1.5 GPH
- Must be 6" from wall on all sides
- Requires ventilation
- Hardwired connection

Note: Chiller must be installed within 15 feet of the dispenser using 3/8" tubing (not included). Standard outlet required.



Water Requirements

Make sure the water valve is 3/8" and the water supply pressure to the water dispenser is between 40 and 105 psi.

Minimum pressure for unit with filter: 40 psi

Optimum pressure: 60 psi

Optimum noise level: Lower than 70 dB



Once installed, complete your fit and finish with drywall and paint.



Unit dimensions:

4-9/16" x 16-3/4" x 20-1/2"



Remote chiller (ERS11Y)

Note: There are different chiller options available for commercial settings. Work with your sales representative to determine the best solution for your needs.

ELKAY INSTALLATION SERVICES CAN HELP. Contact 800.952.8064 or installservice@elkay.com.