
Item Number: A04718

WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **40W** per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture


before starting assembly and installation please prepare the needed tools as below picture				
				Conversion of the second secon
Ladder	Phillips head.flat blade screwdriver	Electrical tape	Pliers	Wire cutter/Stripper
PARTS TYPE (C) Mounting p (D) Green grou (E) Canopy (1) (F) Swivel joint (G) Knob nut (2) (H) Tube (I) Lampshade (J) Socket (8) (K) Arm (8) (L) Arms asser	und screw (1) (1) (1) (8)		OUTLET BOX	—C —D —E —F —G —H
 (A) Plastic wire (B) Mounting s ASSEMBLY & II INSTRUCTIONS 1. Carefully remove carton and chemical 	screw (2)			

2. Turn off power

the above illustration.

Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
- » Place the wall switch in the "OFF" position.
- 3 » Unscrew knob nuts (G) from canopy (E) then remove mounting plate (C).



Ŀ

www.ihomeangel.com

K

E

F

Н

L

BOX

ET

4 » Adjust arms (K) to the proper position.

- 5 » 1) According to your desired hanging height to choose and use tubes (H). Then pass the fixture wires through the chosen tubes (H),
 - swivel joint (F) and canopy (E). 2) Be sure that all the threaded pipes are tightened, then screw the chosen tubes (H) onto swivel joint (F) and the top of arms assembly (L). Hand tighten till snug.

- $6 \gg$ Attach mounting plate (C) to the outlet box with mounting screws (B).
- 7 » Make wire connections

Connect wires as below wires connection shown. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

Connect ground wires according to the below chart Connect wires according to the below chart Connect Black or Connect А B Red Supply Wire to: White Supply Wire to: Black White OUTLET BOX OUTLET BOX GROUND GROUND *Parallel cord (round & smooth) *Parallel cord (square & ridged) Clear, Brown, Gold or Black Clear, Brown, Gold or Black without tracer with tracer FIXTURE FIXTURE GROUND GROUND Insulated wire (other than green) Insulated wire (other than green) with copper conductor with silver conductor CUPPED *Note: When parallel wires (SPT I & SPT II) DIMPLES WASHER are used. The neutral wire is square shaped GREEN GROUND GREEN GROUND or ridged and the other wire will be round in SCREW SCREW shape or smooth (see illus.) Neutral Wire Twist wires together with plastic wire connectors until tightly joined, and wrap each connector with approved electrical tape. Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.


+1 850 296 2377 Working hours : Mon - Fri 9:00 a.m. - 16:00 p.m. EST 🛛 🕅 homecustomercare@outlook.com

Raise canopy (E) to the ceiling and secure canopy (E) in 8 » place by tightening knob nuts (G) onto the pre-assembled screws in mounting plate (C).

> Note: canopy (E) should be snug against the ceiling and knob nuts (G).

> If not, adjust the threaded length on mounting plate assembly (C):

- first, unscrew the pre-assembled hex nuts;
- then, screw the pre-assembled screws in or out of mounting plate (C);
- when the secure length is achieved, tighten the hex nuts and back to step 8.
- 9 » 1) Place lampshades (I) on sockets (J).
 - 2) Install bulbs (not included) (Please do not exceed the maximum wattage recommended on the socket.)



10. Check everything is already installed properly, then you could turn on the light. Enjoy!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.