
ASSEMBLY INSTRUCTIONS N729P285513




Before Installation


Important-Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- •We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- •Keep children and animal away from the work area, small parts could choke if swallowed. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions








				\$ 3 3 5 5	
Ф 6х35mm	Ф 15х9.5mm	Ф 6х30mm	M3.5x12mm		M4x12mm
A x 18+1	B x 18+1	C x 22+2	D x 16+1	Ex1	F x 12+1
March College	ACTURED TO THE PARTY OF THE PAR				
M4x35mm	M6x60mm		Ф 35mm		Ф 8х40mm
G x 4	H x 2	l x 2	J x 2	K x 4	Lx2
Ф 5х25mm					
M x 4					


Step 1 A x 5 A x 5 A x 4 Ф6х35mm A x 14 Step 2 4 3 B x 5 ⁰0 5 C x 3 **Φ**15x9.5mm Ф6х30mm С х 3 B x 5


Step 3 C x 3 3 5 Ф6х30mm С х 3 Step 4 1 B x 5 3 5 Φ15x9.5mm B x 5





Step 6






















Step 8 C x 8 1 Ф6х30mm С х 8 Step 9













Door to the left


Door to the right





















To adjust the vertical height.


Loosen the four screws "c" on both hinges.Two of them are usually in slotted holes which allows you to adjust up or down by a few mm.Then tighten back up.



To adjust depth.

Loosen screw "a" and adjust door,if the door can not be adjusted,please loosen screw "b" ,then try again. Tighten screw "a" and "b" .






To adjust side ways.

Turning the screw "b" on BOTH hinges on each door.

Door to the left Door to the right



or

