# Installation Steps

**1** Connect the pole adapter and rake head

**2** Connect the metal braces to rake head and pole adapter

**3** Connect the rake head assembly to the pole handle and pole extensions

**4** Ready to use