


STEP 1: Screw on threaded tube.




STEP 2: Remove the lamp cap, install the lampshade, and then tighten the lamp cap.



If you need to replace the bulb inside the intermediate lamp cover:

1. Please turn off the power before replacing the light bulb.
2. Gently tear off the cloth beneath the lamp base
3. After unscrewing the nut on the left side of the picture, separate the lamp stand from the lampshade to replace the bulb.



Caution:

Do not remove the lamp with power on. Stay away from fire, direct sunshine, higher temperature and wetness. Never put it in the washing room. Do not touch the shade when with the power on for too long to avoid burning your skin. This stained glass product has been protected with mineral oil on the surface as a part of the finishing process. Please use a soft dry cloth to remove any excess oil.