







INSTRUCTION MANUAL



A	50+2pcs	B	8+2pcs	C	14+2pcs	D	8+1pcs	E	2set (8pcs)	F	6pcs
											
		M3.5*35mm		M8*30mm				M300mm			
G	52+2pcs	H	12+1set	J	30pcs	K	1pcs				
											


Step 1

A=2
C=1




Step 2

A=2




Step 3

A=2
C=1




Step 4

E-1=2
E-2=2
G=8




Step 5

A=6
C=2




Step 6




Step 7

A=6
C=2




Step 8

A=2




Step 9

A=4
C=2




Step 10




Step 11

A=2




Step 12


A=4
C=2




Step 13




Step 14




Step 15



Step 16




When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:




Step 17 X2

E-3=2
E-4=2
A=8
B=8
G=8



Step 18



Step 19

H=12
J=30

