



HIDE IT WITH STYLE

Box Contents

EC18027/EC18028

SCREEN FRAME



A

Left Post (2)
 $\frac{7}{8}$ " x 2" x 48"




B

Right Post (2)
 $\frac{7}{8}$ " x 2" x 48"




C

Post Anchor (4)
 $\frac{3}{4}$ " x $1\frac{1}{4}$ " x 15"



D


Rail (4)
 $\frac{5}{8}$ " x 1" x 39 $\frac{7}{8}$ "



E

Board (8)
 $\frac{3}{8}$ " x 10" x 39 $\frac{7}{8}$ "


SMALL PARTS



F


Joiner Clip (2)

SCREWS



G

$\frac{3}{4}$ " Self-Drilling Stainless Steel Screw (20)



H

1 $\frac{1}{2}$ " Self-Drilling Stainless Steel Screw (8)