

Use and Care Instructions




For outdoor & camping use!

**IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY
PLEASE READ ENTIRE INSTRUCTION SHEET BEFORE ASSEMBLY!!**

ITM. DMSC02
Adult Hammock Chair


IMPORTANT!!

CHECK TO MAKE SURE YOU HAVE ALL THE PARTS!!

A	Chair Body	
		QTY
		1
B	Fabric Cover	
		QTY
		1
C	Carry Bag	
		QTY
		1


STEP 1.

Take the chair body(A) and fabric cover(B) from carry bag.




STEP 2.

Open the chair by holding the top hinges(D) until the leg stabilizers firmly onto ground.




STEP 3.

Lift the support tube(E) up until they fit into the groove of the hinge.



STEP 4.

Attach the plastic cap on the cover to the end of the support tube.



Caution:

Please read the following instruction carefully before assembly to prevent personal injury.

1. Do not use it on uneven ground.
2. Weight limit 350lbs(158kg) according to testing.
3. Open and close chair by holding the top plastic hinges, open until the leg connector and all the 4pcs leg stabilizers firmly onto ground.
4. Keep fingers away from where the part connect.
5. Place both hands on top cap of support tube when getting in or out of chair.
6. Do not attempt to relocate chair while sitting, always keep stabilizers on the ground.
7. Do not stand on the left and right sides of chair when you removing the fabric covers, since the support tube may fall down cause personal injury.
8. Do not allow children to assemble or disassemble the product in case of personal injury.
9. Children should use this chair under the guidance of adults.

Fabric care:

Fabric and frame may be sponged with mild soap and water or simply hosed down.

NOTE: Never use bleach or detergent on the fabric.

Made in China