



DESCRIPTION

Tekwood is a wood-alternative material developed from polystyrene, an HDPE material with foam additives. Tekwood is available as an option for the Oxford Garden Travira Collection in either natural or vintage finish. Designed for the outdoors, Tekwood provides the look and feel of wood with minimal weathering or maintenance.

CARE AND MAINTENANCE

Tekwood products should be cleansed using a mild, non-abrasive cleanser and rinsed well. Over time, Tekwood's color may darken slightly if exposed to sun and other natural elements. This process cannot be reversed, but does not affect the structural integrity or aesthetic of the product. To prolong this process, Oxford Garden recommends bringing furniture indoors or covering when not in use or during non-seasonal months. Tekwood has the potential to stain. To help prevent staining, use a furniture polish or protectant that is labeled safe for plastic materials prior to use.

HIGH TEMPERATURE DISCLAIMER

Magnified sunlight will burn Tekwood material leaving a burn mark. Some glassware and stemware are capable of creating a magnifying effect when in direct sunlight. To avoid this potential damage, select glassware and stemware that does not magnify sunlight. Cigarettes and open flames will also emit enough heat to create a burn mark on Tekwood material. To prevent this damage, do not subject Tekwood to cigarettes or open flame.

WARRANTY

Oxford Garden provides a three-year limited structural warranty and a one year limited material warranty for Tekwood products. For more information regarding the Tekwood warranty, visit www.oxfordgarden.com/warranty.

ABOUT OXFORD GARDEN

For more than 15 years Oxford Garden has produced quality furniture for the outdoors. Based in Louisville, Kentucky, our focus is to provide outdoor furniture with extraordinary craftsmanship, graceful design and lasting beauty. Every piece of furniture is commercial grade and built for superiority and strength.



GENERAL CLEANING

Tekwood can be cleaned with a cloth using most any household cleaning solution, even dish washing liquid. Rinse well after cleaning.

* Recommended
303 Indoor and Outdoor Furniture Cleaner



DEEP CLEANING

For stubborn grease stains, scrub lightly following general cleaning instructions, using Scotch-Brite Scour Sponge or Heavy Duty Scour Pads.



PROTECTION

A routine application of a furniture polish or protectant that is labeled safe for plastic materials is recommended to provide resistance to stains.

* Recommended 303 Indoor and Outdoor Furniture Protectant