

Ceiling Light Installation Instruction


Please read the instruction manual carefully before using.

Dear Customer,

Thank you for choosing this lamp! To save your time and effort, please try to light up the lamp before installation to ensure the sockets are working correctly. If you have any issue when you receive it, please contact us . We will offer you a solution without you even having to send the broken light back. Thank you for your understanding.

- Customer Support Team

Specification		Package List	
Voltage	110-120V	Rattan shade	1
Bulb Socket	E12	canopy	1
Wattage	Max 40W / bulb	Lampholder+Wire	1
Bulb Type	Incandescent/LED/Halogen (Not Included)	Instruction manual and screw package	1
Certification	Sockets are UL Listed		
Warranty	2 Years		



Installation

①Align the bottom of the ceiling plate with the hole on the cover, and tighten it with screws and nuts.

②Attach the metal bracket to your junction box with Phillips head screws. (Anchor screws are only useful for those customers who do not have a junction box).

③ Connect the "L" wire to your "live" wire through the orange terminal caps and the "N" wire to your "neutral" wire, the copper wire needs to be wrapped around the green screw.

④Make the two holes on the canopy align with the screws sticking out of the metal bracket, and then fix them by the nuts. Insert the bulbs.

Q: The lamp does not work?

A: First, make sure your bulbs are working well. If your bulbs work, but not on the lamp, please pull the legs of the bulbs to the sides. This operation is to ensure that the bulb makes good contact with the copper in the bulb socket.