




Assembly Instructions



Model No. HOGA-XK00383X

Multifunctional Computer Desk

Call us!

We're here to help!

If you have any issues with this product, please contact our customer service team before returning it.



We want you to be completely satisfied with your purchase! If anything is missing, damaged, incorrect, or not what you expected, don't worry. Please keep the outer packaging and take photos of both the packaging and products, and then reach out to us at support@tribesigns.com or call us at 1-424-220-6888. We'll take care of everything and send you a free replacement, so you can enjoy your purchase as soon as possible without any hassle.

Assembly Instructions:

1. Carefully read these instructions and keep them for future reference.
2. Refer to the parts list for guidance and ensure that you have all the pieces before starting the assembly process, if anything is missing, damaged, incorrect, contact us **FIRSTLY BEFORE** assembling.
3. When assembling, place all parts on a soft, clean, and flat surface, such as a carpet, to prevent any scratches.
4. To avoid misalignment of the holes, Please don't full tighten the screws until you ensure all parts in place.

Follow Tribesign:



Facebook



Twitter




Pinterest





YouTube




Instagram










X2




When using the electric screwdriver ,
Reduce the power and torque to avoid damaging the furniture




?



X

















✓




Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for free replacement if having damaged or missing parts.


Parts & Hardware List

 1 1pc	 2 1pc	 3 1pc	 4 1pc
 5 1pc	 6 1pc	 7 2pcs	 8 1pc
 9 1pc	 10 1pc	 11 1pc	 12 1pc
 13 1pc	 14 6pcs	 15 4pcs	 16 2pcs


Parts & Hardware List

 F 39pcs	 H 8pcs	 I 4pcs	 N 18pcs	 M 4pcs	 R 4pcs
 U 2pcs	 V 3pcs	 W 4pcs	 X 2pcs	 Y 4pcs	 Z 1set
					



1



2





3





4



Pay attention to the position of the holes.





5





6




7




8




9




10






Instructions for using light strips




R



Z


The buckle serves as a fixing effect

11



F x12

12




No heartburn, when we handle the return

Our way



support@tribesigns.com



Replacement/Refund



You

Their way



Re-package item



Schedule pick-up



Track package



Replacement



You

Contact our customer service team



support@tribesigns.com
www.tribesigns.com



1-424-220-6888