INSTRUCTION MANUAL

Gazebo with Sidewall Curtains G30004



We offer a diverse range of products to meet the needs of customers.

Outdoor Furniture

We are a professional furniture provider with top-notch factories and outstanding designs, Our mission is to provide consumers with new lifestyles. By collecting consumer feedback, we constantly improve our products and create more choices for consumers. If you want to create your space, We are an ideal choice.

Always.



WARNING

Ensure that all parts and hardware are available before beginning assembly

3

- In case of windy weather, please do not stand in the gazebo.
- Please do not stand under the gazebo in case of heavy snowfall.
- For safety, please use expansion screws to reinforce the posts to the ground.
- In windy weather, please tighten the fence and netting to avoid tearing in high winds.
- In extreme weather conditions, you can use a rope to pull the four corners of the gazebo to keep it stable.
- Please clear the snow off the roof in time for the heavy snowfall.
- Make sure all screws are tightened before use.
- Repeat to confirm all screws, buckles and straps every 90 days.
- Please keep all screws loose during the assembly process and tighten them after completing the installation.
- Do not use or store next to a pole with an open flame or flammable chemicals.
- Please note that some parts have sharp edges and should be handled with gloves.
- If any parts are missing, broken, damaged or worn, discontinue use of the product until repairs are made or factory replacement parts are installed.
- Installation of the product in a manner that does not conform to the manufacturer's instructions may result in the loss of the warranty policy for this product.

① CALIFORNIA PROPOSITION 65

WARNING: This product can expose you to Carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to <u>www.P65Warnings.ca.gov</u>

TOOLS REQUIRED



ATTENTION :

1.Please read this instruction carefully before installation and follow it strictly during installation.

2. Ensure that there are no problems later due to installation errors.

3.We have prepared extra screws for you to use in case of loss or damage.

Installation Notes

Please check the quantity of all parts before installation (Please refer to the Parts Lists) and the appearance of the products. Please make sure the product is correct before installation. If there is any problem, please contact us directly.

Make sure the colored panels are facing outwards and all the holes match. The panels are textured, please install the panels in the order specified in the instructions. All lines and holes must be accurately matched to make the storage shed more stable. Please ensure that all screws are tightened to prevent the product from falling apart.

There is a protective film on the surface to protect the product, please tear it off after installation to get the final presentation. If you do not damage the film during installation, it can also remain on the product to protect the product.

Please place the product on a flat ground to prevent leaning and collapse. If the ground is uneven, the door may can't be closed.

🛕 Safety Precautions

We recommend two adults to complete the installation. Two adults installed together will make the installation process easier and safer.

The gloves must be carried to prevent hand cuts during installation.

Take care when using power tools near water the use of a residual current device (RCD) is advised. Please use the electric driver carefully during screwing to prevent the screw from slipping and hurting your hand. (We recommend that beginners use a manual screwdriver for installation.) Be careful not to fall when installing the roof. Please steady the ladder and make sure the product placed on a flat ground.

PLEASE KEEP THIS INSTRUCTION FOR FUTURE REFERENCE.













Place the connecting part "O" in the right frame of part "B1" and in the left frame of part "B".



3 Connecting part "B" and part "B1" with 12 screws "U"





A part "Q" and a part "Q1" are connected with a screw "U2" on the outside of the connection.



Place the connecting part "O" in the right frame of part "C1" and in 5 Place the connection of the left frame of part "C".

Connecting part "C" and part "C1" with 12 scews "U".







Four part "Q1" is fixed at the top with Four screw "U2".



8 Attach the ends of part "C" and part "C1" to the top of part "A", using six screws "V" to connect the two sides.



9 Attach the ends of part "B" and part "B1" to the top of part "A", using six screws "V" to connect the two sides.





Connect the four parts "P" to the four corners and fix them with 16 screws "U1".





PART	NO.	ଭ୍ସୁ Y.
a	Ρ	4
()=>	U1	16

11 In the interior view of the gazebo, eight parts "H" are attached to the sides of the columns using 16 screws "U".





PART	NO.	<u>ଭ</u> ाभ.
Certain and the second	Н	8
	U	16



Four parts "H1" are attached to the four corners using 8 screws "U3".





Notice: When installing screws, please put the screws from the middle space, not directly from the top.



13 1.Connect the part"D2"and part"D"with 2screws"U4" 2.Connect the part"D1"and part"D2"with 2screws"U"





Notice:Repeat the above steps to connect the remaining 3 parts"D1" 3 parts"D2" and 3 parts"D"

14



PART	NO.	ଭ୍ସୁ .
	S	1
	U1	8



Connect 4 parts "D1" to part "S" and fix them with 8 screws "U". 15 Fix part "V3" through part "S".



PART	NO.	ଭ୍ସୁ ୧
	S	1
U	V3	1
	U	8



Move the whole roof to the shelf and fix the part "D" with four screws "U".





1.Connect the part"E3" and part"E2" with 2screws"U" 2.Connect the part"E3" and part"E" with 2screws" U4"





Notice:Repeat the preceding steps to install the remaining components





19 Use 4 parts "Y" and 10 screws "U" to fix part "K1" and part "K".





Place part "R" on the top of part "S" and secure it with two parts "V1".



	R	1
ş	V1	2



First, place part "L1", part "L2" and part "M4" on the open space in the order of installation, so that they can be installed in order during installation.



Place two parts "M4" in the middle of part "L1" and part "L2".

PART	NO.	QTY.
	L1	4
	M4	2
$\square \square$	L2	4



Use 4 screws "U" to fix the part "Y" in the four corners Fix the part "X"with 6 screws "U".













The correct part location is shown in the figure below.





The panel mounting method is as follows



PART	NO.	ଭ୍ସୁ ହ
	M5	4
	N5	4
	П	4
	J2	4



The positions of parts "F", "F1" and "F2" are as follows.



Use 6 parts "X" and 6 screws "U" to fix parts "F" and "F2". Use 4 parts "Y" and 4 screws "U" to fix parts "F" and "F1".







PART	NO.	QTY.
3	Y1	4
	U	8
ŵ	Z	112

Zx6 Zx6

ति





Hang part "W" and part "W1" on part "Z", with 8 holes on the long side and 6 holes on the short side.





Notice: After installing parts "W" and "W1", fix them to part "A".



HELP CENTER

Question about your product? We're here to help. Visit us at:











Chat Support

Product Inquiry

Orders FAQ

Product Assembly Returns & Refunds

We Stands Behind the Quality of Their Furniture

If you have any issues with your item please let us know! We will always do our best to come up with a solution that you will be happy with.Please get in touch with our customer service team before returning the product.

And pls do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase. In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.

2.Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.

3.You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).

4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

Return Request

In order to get a full refund as described in this return policy, all items must be:

(1) In a brand new/unused condition, please provide photos before and after packaging.
(2) When returning, all accessories and parts are firmly packed in all original packaging.
If your return does not meet the requirements, you may not get a full refund.

When will I be refunded?The refund is released once the goods have been returned to our warehouse.What if the product is damaged/defective outside of the valid return period?We want you to be a happy customer.

Please reach out to us by email and we will come up with a solution to make sure you are satisfied.