


ASSEMBLY INSTRUCTIONS



ITEM NO. FB3041HAY-SC-4PK



ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#1		Back frame	1pc x4
#2		Seat frame with cushion	1pc x4
#3		Front Legs	2pcs x4

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#A		Bolt Ø1/4" x 3"	4pcs x4
#B		Bolt Ø1/4" x 2-3/8"	4pcs x4
#C		Bolt Ø1/4" x 1-1/2"	2pcs x4
#D		Spring washer Ø1/4"	10pcs x4
#E		Flat washer Ø1/4"	10pcs x4
#F		Allen key M4	1pc x4



STEP 1:




STEP 2:




Do not tighten screws until completely assembled.

STEP 3:




STEP 4:



Tighten all screws until completely assembled.

ASSEMBLY INSTRUCTIONS

ITEM NO. FB3041HAY-T



ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#1		Table Top	1 pc
#2		Table Legs	4 pcs

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#A		Bolt 5/16" x 2-1/4"	8 pcs
#B		Spring washer Ø5/16"	8 pcs
#C		Flat washer Ø5/16"	8 pcs
#D		Allen key M5	1 pc



STEP 1:



STEP 2:



Tighten all screws until completely assembled.