
ASSEMBLY INSTRUCTIONS

ITEM NO. FB3056HAY-RT





ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


Part List					
NO.	DIAGRAM	PART NAME	Q'ty		
#1		Table Top	2pcs		
#2		Long Connect Panel	1pc		
#3		Short Connect Panel	2pcs		
#4		Leg 1	1pc		
#5		Leg 2	1рс		

Part List					
NO.	DIAGRAM	PART NAME	Q'ty		
#A		Metal Bracket 100 x 100 x 3mm	1pc		
#B		Wood Dowel Ø10 x 30mm	4pcs		
#C		Bolt Ø1/4" x 1-1/4"	28pcs		
#D		Spring washer Ø1/4"	24pcs		
#E		Flat washer Ø1/4"	24pcs		
#F		Allen key M4	1pc		











Do not tighten screws until completely asembled.



ASSEMBLY INSTRUCTIONS

ITEM NO. FB3056HAY-SC-4PK





ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Part List					
NO.	DIAGRAM	PART NAME	Q'ty		
#1		Back frame with cushion	1pc x4		
#2		Seat frame with cushion	1pc x4		
#3		Front Legs	2pcs x4		


Part List					
NO.	DIAGRAM	PART NAME	Q'ty		
#A		Bolt Ø1/4" x 3"	4pcs x4		
#B		Bolt Ø1/4" x 2-3/8"	4pcs x4		
#C		Bolt Ø1/4" x 1-1/2"	2pcs x4		
#D		Spring washer Ø1/4"	10pcs x4		
#E		Flat washer Ø1/4"	10pcs x4		
#F		Allen key M4	1pc x4		







Do not tighten screws until completely asembled.



Tighten all screws until completely asembled.