





TABLETOP CHARCOAL GRILL

17" RECTANGLE GRILL ASSEMBLY INSTRUCTIONS











ASSEMBLY DIAGRAM




INCLUDED PARTS




1	Handle		x3
2	Air vent		x2
3	Lid		x1
4	Cooking grid 16" x 10"		x1
5	Charcoal grid 13" x 8 "		x1
6	Bowl		x1
7	Air vent switch		x1
8	Air vent		x1
9	Leg		x2

A	.6 mm		x6
B	.4 mm		x4
C	M4		x4
D	Ø6x16		x10
E	Ø4x10		x4
F	Ø4		x2


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



Questions or Comments?

call 1-888-508-4750 or visit www.brandbuzzcp.com

Developed in USA | Responsibly Made in China ©2022
Distributed by Brand Buzz LLC, 1407 Broadway, New York, NY 10018

Kingsford and logo are registered trademarks of The Kingsford Products Company LLC.
and are used under license by Brand Buzz LLC. All Rights Reserved.