

TOUGH GUY INFLATABLE PUNCHING BAG

MODEL# 8916TG

PRODUCT MANUAL - VERSION 5.20.01

FOR AGES:

4-10

WEIGHT LIMIT:

N/A



TOOLS NEEDED:









CUSTOMER SERVICE INFORMATION

Thank you for purchasing: **TOUGH GUY PUNCHING BAG**

MODEL# 8916TG

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQBrands®, we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase.

To register you product please visit: www.globalgualitybrands.com/product-registration or Scan code:



To order these parts, or if you have any other questions or concerns about this GQBrands product, please contact us at

PureFun.net **GQ** Brands

Phone: 1-866-498-5269

Email: CustomerService@GQBrands.com 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:	
YOUR NAME:	RETAILER WHERE PURCHASED:
YOUR MAILING ADDRESS:	DATE OF PURCHASE:
YOUR EMAIL ADDRESS:	ORDER NUMBER: (If Available)
PRODUCT NAME:	PO NUMBER ON BOX: (If Available)
PRODUCT MODEL#:	QUANTITY NEEDED:
PART NUMBER	SERIAL NUMBER:

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 90 DAYS FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company

All warranty coverage extends only to the original retail purchaser from the date of purchase, GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS® SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQBRANDS® CAN WAIVE OR CHANGE.







ASSEMBLY INSTRUCTIONS

INSTRUCTIONS:

- 1. Twist and remove the cap and the plug from the base of the bag.
- 2. Pour water into the base until the base of the bag is completely full.
- 3. Replace the plug, and screw the cap tightly back on to the base of the bag.
- 4. Securely close the valve.
- 5. Locate the air valve on the side of the bag and open.
- Inflate the bag with standard Foot Pump (NOT included). Fill until bag is upright and most of the wrinkles have straightened out.
- 7. Close air valve and push gently into the body.

NOTE: Be careful not to over-inflate the bag. You should be able to depress your finger in to a depth of about 2" when fully inflated.



⚠ WARNING/ADVERTENCIA

- For Ages 4-10. Not Suitable for children under 3 years of age.
- Never wear rings or hold hard or sharp objects while using this product.
- Always check for proper bag inflation and ensure base is properly filled with water prior to use.
- The Bag bounces back when in use. To avoid possible injury keep at a safe distance during play.
- Adult supervision is required.
- Do not allow persons to stand or sit near product while in use.
- Never stand or sit on product.
- Do not over inflate bag.
- Keep away from open flame and any pointed objects.
- Do not use the bag if it is not fully inflated.

CUSTOMER SERVICE

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com or toll-free at 1-866-498-5269

PureFun.Net GQBrands®

Phone: 1-866-498-5269

Email: CustomerService@GQBrands.com

4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

FREQUENTLY ASKED QUESTIONS

Question: "Is there any maintenance I need to do for this?"

Answer: Before each use, you should always double check to make sure there are no holes and base is full of water.

Question: "Something was missing from the packaging," "I need to purchase a replacement part" or "I discovered a damaged piece. What should I do?"

Answer: Contact customer service. You must have your proof of purchase and/or order confirmation available to be considered for warranty replacement. You must report missing pieces within 30 days from the date of purchase.

Question: "How should I clean my bag?"

Answer: you should clean this equipment a solution of warm water and non-corrosive and/or non-abrasive soap. Dampen a rag with this solution an swipe completely dry before using.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net

Use Code: GQBRANDS10 at Checkout



