













## ASSEMBLY INSTRUCTION

When you buy One item ,might you will receive 2 or more boxes. Due to the carrier , all the boxes cannot arrive at the same time. Please wait patiently for the rest of the boxes to arrive.

### Assembly Tips:

- 1) Before assembly , please confirm that the parts are complete.
- 2) Hand tighten all the bolts to line up all the pieces. Tight all the screws to 60% first then tight to 100%.
- 3) If the screws are not tight or twisted, do not use gravity, first loosen the adjacent holes, align each hole, and then tighten.
- 4) If you received the product with missing accessories\damaged parts\ assembly problems, please do not worry. please provide your order number and pictures of your damaged parts, and sent your problems to mail :  
[info@foresthomes-us.com](mailto:info@foresthomes-us.com);[info2@foresthomes-us.com](mailto:info2@foresthomes-us.com);[sales@unityfidek.com](mailto:sales@unityfidek.com)
- 5) Our team members are more than happy to help.



A		D790*W910*H680mm	x2
B		D790*W790*H680mm	x2
C		D790*W670*H680mm	x1
D		D655*W655*H350mm	x1
E		640*640*5mm	x1
F		D640*W640*H350mm	x2
G		650*650*100mm	x3
H		650*630*100mm	x2
I		630*630*100mm	x2
J		650*420*180mm	x5
K		420*420*150mm	x4

