




59104RWD JUMPER WIRE INSTRUCTIONS

If using the 59104RWD with only one load you must attach a jumper wire from the left-most terminal to terminal 3 as shown in the diagram below. If you do not, the timer will not function properly and will not turn to keep time.



If you are using the 59104RWD with two loads, no jumper wire is needed and the unit should be wired as shown below.

