






# USE AND CARE MANUAL

## ADJUSTABLE TABLE LAMP



### Hardware (Parts are not to scale)

<p>H1 Socket ring (Pre-assembled to the socket of socket assembly (A)) 1 pc</p> 	<p>H2 Tube connector (Pre-assembled to base (E)) 1 pc</p> 	<p>H3 Allen screw (Pre-assembled to base (E)) 1 pc</p> 	<p>H4 Allen key 1 pc</p> 
---	---	---	--

**THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.**

---

# IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids.
  - Never cover the lamp with any object including cloth or paper as this is a fire hazard.
  - Do not handle the bulb immediately after the light is turned off as it will be hot.
  - This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
- 

## PREPARATION

- Before beginning assembly, installation or operation of product, make sure all parts are present. Compare parts with package contents list and diagram on previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.
- 


## ASSEMBLY

---

### 1 Assembling the tube to the base

- Unscrew the Allen screw (H3) from the tube connector (H2), then remove the tube connector (H2) from the base (E).
- Tighten the tube connector (H2) to the bottom of tube (D).
- Align the hole on the tube connector (H2) with the hole on the base (E). Using Allen key (H4) tighten the tube (D) to the base (E) with Allen screw (H3).

**NOTE:** Before securing the Allen screw (H3), making sure the tube (D) is facing the front of the lamp.





---

## CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

---

## TROUBLESHOOTING

- The light does not come on at all:
  - a) Ensure the power supply is turned on.
  - b) Ensure the cord is plugged into an outlet.
  - c) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
  - a) Check for crossed wires, ensure wiring is correct.