



For longer use

Re-tighten bolts every 6 months by using the enclosed allen-key. *Using an electric drill can damage the chair. Please re-tighten bolts manually.



Safety Information





Do not sit at the front

edge of the chair



Do not stand on the

chair



Do not use the chair

with more than one

person

Sit in the center of the chair, with your back to the backrest








Do not push the chair around when a person is sitting in it

Do not push down on the backrest when a person is reclined

Do not place all your weight on only the backrest

INSTRUCTION MANUAL



Package List





0



(A)*1 Stool Surface

(B)*1 Tray (C)*1 Co

(C)*1 Conjoined support (D)*1 Air Rod





(E)*4 Bolts



(F)*1 Wrench







CAUTION:

* Before using the chair, check to ensure that all bolts are fully tightened.

* Lubricate all parts and tighten all bolts every 6 months or whenever needed. **NOTE:** 1. All bolts are 100% tightened.