

INSTRUCTION MANUAL



Creative Fan Light



CEILING FAN WITH LIGHT

Installation & Troubleshooting Manual

Scan the code to view the installation
video



※ Note: The installation process for other designs follows the same steps; please read the instructions carefully before installing.

CONTENT //

1. SAFETY RULES	01
2. TOOLS REQUIRED	02
3. ACCESSORY	03
4. INSTALLATION	04
5. REMOTE CONTROL OPERATIONS	05
6. MOBILE APP CONTROL OPERATION	06
7. MAINTENANCE AND CLEANING	07
8. TROUBLESHOOTING GUIDE	08
9. WARRANTY INFORMATION	09

SAFETY RULES

1. To reduce the risk of electric shock, turn off the electricity to the fan at the main fuse box or circuit panel before beginning.
2. All wiring must be in accordance with the local electrical codes or National Electrical Code. Electrical installation should be performed by a qualified licensed electrician.
3. To avoid personal injury, the use of gloves may be necessary while handling fan parts with sharp edges.
4. Make sure the installation site you choose allows clear space for the blades to rotate and at least 7 feet (2.13 meters) of clearance between the floor and the fan blade tips.
5. **WARNING:** To reduce the risk of fire, electric shock, or personal injury, mount fan only to an outlet box marked acceptable for fan support and use mounting screws provided with the outlet box. Most outlet boxes commonly used for the support of lighting fixtures are not acceptable for fan support and may need to be replaced. Consult a qualified electrician if in doubt.
6. The outlet box and ceiling support structure must be securely mounted and capable of supporting at least 20 KGS.
7. To avoid personal injury or damage to the fan and other items, be cautious when working around or cleaning the fan.
8. Do not use water or detergents when cleaning the fan or fan blades. A dry dust cloth or lightly dampened cloth will be suitable for most cleaning.
9. After making electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box.
10. Electrical diagrams are for reference only.
11. The fan is more suitable for indoor use.

TOOLS REQUIRED



Electric drill



Wrench



Ladder



Pincer





Screwdriver



Tape

Accessory

Unpack your fan and check the contents.
You should have the followings:



Expansion Screws*4 sets
(for fixing the holder on the ceiling)



screw*4




small screw*4



screw and
nut *9pcs



washer*9pcs



connecting the
light band*9pcs



nut *4



Small Wrench*1



Cable tie*3


INSTALL THE FAN

Tools Required: Screwdriver, Pair of Pliers, traight slot screwdriver, Adjustable Wrench, Step ladder and Wire Cutter5


INSTALL THE MOUNTING BRACKET

To prevent personal injury and damage, ensure that the hanging location allows the blade a clearance of 7 feet (2.13meters) fromthe floor.if there isn't an existing CUL listed mounting box, then read the following instructions!


1. Take out four screws of accessory package and use them as shownin the illustration.



2.
When installing on a wooden ceiling, the mounting bracket is fixed tightly with wooden tooth screws or crossbeams.



2.
To install on the concrete ceiling, use 8mm impact drill bit to drill depth of 50mm firstly, then use the expansion screws in the accessory package to fix the mounting bracket on the ceiling.



Attention: Please use 8mm diameter drill bit to drill hole first, and then use M6 expansion screws for installation.




Please note:


- 1. If you use a wooden ceiling as the installation surface, please ensure that thickness of wooden board at the installation location is not less than 30MM and weight force is not less than 30KG
- 2. To ensure reliable fixation, please use the corresponding fixing screws according to the above instructions when installing on ceilings of different materials.

WIRING INSTRUCTIONS

1.
Please follow instructions to connect all the power cords to connecting terminal.



2.
Please tighten the main part of the fan light and the holder using four screws.




Attention:




1. Before installation, carefully check the appearance of the fan light. Contact us for help if there is any paridamaged.
2. Make sure the power is off before install ation.
3. Make sure the L lines and N lines are well wired or there would be abnormal light flash.

INSTALLATION STEP INSTRUCTIONS




1.Unscrew side screws and remove the mounting bracket



2.Fix the flower shape light band as shown by tightening screws and spacers,screws and cables are pre-installed, no extra screws are needed


3.
Connect acrylic decorative
partsto the main body
using 4 screws



4.
(1) Attach the fan
blade to the main
part
(2) Rotate the fan
cap counter
clockwise to fix the
fan

5.
(1) Install expansion
screws on the ceiling
(2) Press the mounting
bracket and fix it with
screws

(3) There is lock with
groove on the main
part, use four screws
to fix the fan light to
the mounting bracket



Remote Control Instructions

Features:

It can realize the core functions of fast device pairing, local control and group control without the gateway. It can be applied to power supply, dual-color temperature lights, colored lights, fan lights, on-off switches etc.

Operations:

- 1.APP Download: Scan the QR code to download the APP, and register an account as per the instructions.
- 2.Add the device: Log in the account, and click “+” to add the device. You can edit the device name and room, and choose the device type (such as fan light).
- 3.Pairing: After adding the device, click the device icon to the detail page. Cutoff the device for 1-2 seconds and then power on. Then click the “Pairing button. If it beeps 2 times, then the pairing is successfully done. Multiple devices are able to be matched at the same time.
- 4.After the pairing is done, then you can use APP to control the devices.



- Remote Code Matching: Long press the “PAIR CODE” button within 5 seconds when the light is turned on. If it beeps 2 times, then the code is successfully matched.
- Match Code
 - Light ON/OFF
 - ALL OFF
 - Color Temperature Switch
 - Small Night Light
 - Click or long press this button to enhance the brightness
 - Click or long press this button to weaken the brightness
 - Long press this button to increase color temperature
 - Long press this button to decrease color temperature
 - Fan rotates forward
 - Fan rotates in reverse
 - Turn off automatically after 2-hour countdown
 - Fan speed, 1 is the weakest 6 is the strongest
 - Nature wind
 - Fan OFF
 - Turn on inducer



APP Download

Mobile App Control Operation



1.
Turn off the lights



2.
Scan the QR code
and download
the app,works with
IOS/Android system



3.
Choose your room
& click "+" to add d
evice(turn on mobile
blue-tooth)



4.
Turn on the light



5.
Turn on wall switch and
click "📶" to pair within
5 seconds

WIRING PART

1.Cleaning Frequency:

Regular cleaning is essential to keep your ceiling fan light looking its best and functioning optimally.We recommend cleaning the fan blades and light fixtures at least once every few months, or more frequently if you notice dust buildup or reduced performance.

2.Safety First:

Before cleaning, ensure that the ceiling fan light is turned off and the blades have come to a complete stop.If your fan has a remote control, remove the batteries from the remote to prevent accidental activation during cleaning.

3.Dusting:

Start by dusting the fan blades and light fixtures using a soft, lint-free cloth or a duster.You can also use a microfiber cloth or a vacuum cleaner with a brush attachment to remove dust and cobwebs.

4.Cleaning the Blades:

For stubborn dust or grime, dampen the cloth or sponge slightly with a mixture of mild dish soap and water.Gently wipe the blades from the base towards the tips, being careful not to bend or damage them.Rinse the cloth or sponge frequently and ensure it is not overly wet to prevent water from dripping onto the motor.

5.Cleaning the Light Fixtures:

If your ceiling fan light has glass or plastic light covers, remove them carefully (following the manufacturer's instructions) for cleaning.Wash the covers with a mild soap and water solution, then rinse and dry thoroughly before reinstalling.

6.Cleaning the Motor Housing:

Occasionally, you may want to clean the motor housing to maintain proper airflow and prevent overheating.Use a vacuum cleaner with a brush attachment or compressed air to remove dust and debris from the motor and housing.

7.Cleaning the Remote Control:

If your fan has a remote control, wipe it down with a clean, dry cloth. Avoid using harsh chemicals that may damage the remote's surface.

8.Avoid Harsh Chemicals:

Never use abrasive or corrosive cleaning agents on any part of the ceiling fan light, as they can damage the finish and components.By following these maintenance and cleaning recommendations, you can ensure that your ceiling fan light stays in good condition, operates efficiently, and continues to provide a comfortable environment in your living space.

TROUBLESHOOTING GUIDE

Before:

1. This is a replaceable light bulb ceiling fan, **DO NOT** install any dimmer switch for this.
2. Install the Remote OR Wall Switch, **DO NOT** install both of them.
3. Check circuit fuses or breakers and make sure the battery is installed correctly.
4. Check line wire connections to the fan and switch wire connections in the switch housing.

CAUTION: Make sure the main power is off.

Problem: Light does not work

1. Check to see that the wire connections in the switch housing are connected.
2. Make wiring connections from the house to the LED light directly (don't connect the remote and the fan) to determine it's the issue of the LED light or not.

Problem: Fan will not start

1. Check line wire connections to the fan and switch wire connections in the switch housing. **CAUTION:** Make sure the main power is off
2. Make the Fan wiring connections Without the Remote & transmitter and the light, to determine it's the issue of the fan body or not.
 - a) Please don't wire the light at the bottom
 - b) Connect the Ceiling Fan Neutral Wire (White) to the Neutral Wire (White) coming through the ceiling. Connect the Ceiling Fan Live Wire (Black) to the live wire (Black or Colored) coming through the ceiling. Then turn on the main power check the fan works separately or not.

WARRANTY INFORMATION

1. Warranty Period:

This product comes with a standard one-year warranty, which begins from the date of your purchase.

2. Warranty Policy:

The warranty policy for this product covers manufacturing defects and material deficiencies. If you encounter issues with the product during the warranty period, we offer the following service options:

- a. Repair: We will take responsibility for fixing or replacing any faulty components to ensure that the product functions correctly once more.
- b. Replacement: If the issue cannot be repaired, we will provide you with a brand-new replacement product.

3. Warranty Claims:

If you need to file a warranty claim, please get in touch with our customer

support team and provide the following information:

- a. Order number of your purchase.
- b. Detailed description of the problem.
- c. Photographic evidence of the product damage.

Our customer support team will guide you through the next steps to obtain repair or replacement services.