



## CARE AND MAINTENANCE DO & DO NOTS

| <b>Do</b>  | <b>Do Not</b>  |
|--|--|
| Do vacuum using a soft bristle attachment  | Do not use vacuum with beater bar  |
| Do use a humidifier, dehumidifier, or air conditioner to help maintain temperature and humidity levels | Do not let your ambient temperature in the room fall outside the range of 60°F - 80°F and a relative humidity of 35% - 70% |
| Do use cleaning solutions specially formulated for laminate flooring                                   | Do not use oil soaps, wax based cleaning solutions, or other chemicals that have abrasive properties                       |
| Do use a slightly damp cloth or paper towel to clean up spills immediately                             | Do not wet mop or use a steam mop  |
| Do clean up spills immediately   | Do not leave standing liquids of any kind  |
| Do apply cleaning solution directly to cloth or mop  | Do not spray liquids directly on floor   |
| Do use protective mats under chairs with castors. Place felt floor protectors under furniture legs     | Do not try to slide heavy objects across floor   |
| Do use entry mats  | Do not try sealing your floor with any aftermarket floor sealer  |