

How to repair a roof to stop leaks

REPAIRING ROOF PROJECTIONS



1. Flashings pulling away from walls should be reset in roof cement.
2. With flashing in place, apply **roof cement** 2-3" above & below where the flashing meets wall
3. Embed **Universal Patching Fabric** into the cement. Spread additional roof cement over the entire repair area.
4. Repeat for bottom of flashing.



REPAIRING CRACKS



1. Cover cracked and damaged area with **Roof Cement**.
2. Cut and place a strip of **Universal Patching Fabric** into the cement. Spread more roof cement over entire repair area and let cure.

REPAIRING ROOF PROJECTIONS



1. Apply roof cement at base of projection. Spread the cement around the repair.
2. Embed **Universal Patching Fabric** into the cement directly over entire repair area.
3. Apply additional **roof cement** over fabric reinforcement to completely seal repair.



REPAIRING BLISTERS



1. Cut an "X" in roofing material where blister is located. Peel back the flaps exposing the underlying surface. Allow area to dry.
2. Trowel **roof cement** into exposed area making sure to cover entire area. Push flaps back down to cover the underlying surface. Cover with additional roof cement.

