



Use & Care

Igloo® Party Bar™

Model# 00049545

Use

Great Outdoors, Sports & Events, Lunch, Parties, Events, Barbecues

Care

Wipe interior and exterior soft surfaces with a clean cloth before and between uses. Spot clean soft surfaces with mild detergent and water, as needed. To prevent stains and odors, empty cooler of contents after use. Tougher stains on hard liner may be cleaned with diluted solution of baking soda and water. Ensure all cleaning agents are thoroughly rinsed and the cooler is dry before storage.