


Thank you for your purchase!



HERCULES Series 21\"W Stacking Church Chair With Arms

ASSEMBLY INSTRUCTIONS

Before You Begin: Chair backs are not pre-drilled, Phillips screwdriver or drill(not included) required.

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.



Online Assembly Instructions: <http://ftp.flashfurniture.com/AssemblyInstructions/XU-DG-60156-BK-GG.pdf>

Customer Service Email: CustomerExperience@belnick.com | phone: 866-552-2810

XU-DG-60156-GY-GG/XU-DG-60156-BUR-GG/XU-DG-60156-BK-GG



PARTS

Chair backs are not pre-drilled, Phillips screwdriver or drill required.



STEP 1

Attach back of the chair (Part 2) to the chair frame (Part 1) using M5x40L screws (Part B) ensuring the chair back is correctly aligned.



.....

Thank you for your purchase!