


ASSEMBLY INSTRUCTION

ITEM : WF318526

DINING CHAIR

If you have any questions, please feel free to contact us.
Email: lowes.team@qualfurn.net



ASSEMBLY INSTRUCTION

ITEM : WF318526

Important Note !

Please read these instructions fully before starting assembly:





1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instruction step by step.
3. Do not tighten all screws and bolts until the chair is fully assembled.
4. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent , do not use bleach or abrasive cleaners.








ASSEMBLY INSTRUCTION

ITEM : WF318526



ASSEMBLY INSTRUCTION





ITEM : WF318526

Part List For One		Hardware List For One	
①		Ⓐ	 M6*40mm
		JCBC BOLT (2PCS)	
②		Ⓑ	 M6*60mm
		JCBC BOLT (4PCS)	
③		Ⓒ	 M6*80mm
		JCBC BOLT (4PCS)	
④		Ⓓ	 M4*32mm
		WOOD SCREW (3PCS)	
		Ⓔ	
		SPRING WASHER (10PCS)	
		Ⓕ	
		FLAT WASHER (10PCS)	
		Ⓖ	
		BUTTON (4PCS)	
		Ⓗ	 M5
		ALLEN KEY (1PC)	



ASSEMBLY INSTRUCTION

ITEM : WF318526




STEP 1





NOTE : Do not fully tighten the bolt

Bolt M6*40mm  (A) x 2	SPRING WASHER  (E) x 2	FLAT WASHER  (F) x 2
BUTTON  (G) x 4	M4 Allen Key  (H) x 1	

STEP 2





NOTE : Do not fully tighten the bolt

Bolt M6*80mm  (C) x 4	SPRING WASHER  (E) x 4	FLAT WASHER  (F) x 4
M4 Allen Key  (H) x 1		



ASSEMBLY INSTRUCTION

ITEM : WF318526



STEP 3




NOTE : Do not fully tighten the bolt

Bolt M6*60mm  (B) x 4	SPRING WASHER  (E) x 4	FLAT WASHER  (F) x 4
M4 Allen Key  (H) x 1		

STEP 4



NOTE : To assist with levelling the chair, place a heavy object have an adult sit on the chair for levelling and fully tighten all bolts with Allen Key(H) to secure all legs.

WOOD SCREW M4*32mm  (D) x 3

ASSEMBLY INSTRUCTION

ITEM : WF318526

COMPLETE

