


TASK PORTABLES



FUNCTIONS

- Short Tap: Turn on
- Tap to cycle through 5 modes:
 1. Upper Light (High/Medium/Low)
 2. Lower Light
 3. Upper & Lower Lights
- Long Tap: Turn off

A P1943-731-L

