

## CARE AND MAINTENANCE

Wipe clean with a soft cloth dampened in water and a mild soapy solution. Wipe dry with a clean and dry cloth.

this shoe rack requires no maintenance

however, by keeping the Product clean and storing it properly you can enjoy it year after year

If there are any questions relating to missing parts, assembly issues or replacements, please send a detailed email to [hello@happimess.com](mailto:hello@happimess.com)






## NOTICE

\* Please make sure that you have all parts indicated before you begin assembly of this item

\* This item Should be assembled on a soft surface to prevent scratching the finish during assembly

\* This item may require periodic tightening


## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	STAND		X1
B	PIPE		X4
C	ROD		X2
D	PLATE	 <div>Top Plate Center Plate Bottom Plate</div>	X1 X1 X1
E	NUT		X2

# happimess

**SRK1002A**

**PRODUCT DIMENSIONS : 38"W x12.5"D x24.5"H**



**Weight Capacity : 50 Lbs**

**Warning : Do not stand on Shoe Rack**

**Warning : Do not sit on Shoe Rack**



**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware content list.  
if any part is missing or damaged, do not attempt to assemble the product.  
Estimated Assembly Time 20 minutes

