

INSTALLATION INSTRUCTIONS

LED CEILING FIXTURE

120VAC Input, Dimmable

READ AND FOLLOW SAFETY INFORMATION


CAUTION - Turn off the main power at the circuit breaker before installing and servicing the fixture to prevent possible injury from electric shock.

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

INSTALLATION & ASSEMBLY

1. Pull the supply wires (4 & 5) and the house ground wire (6) out from the outlet box (1). Connect the power supply wires to the fixture lead wires by connecting the black fixture wire (9) to the black supply wire (5), and the white fixture wire (8) to the white supply wire (4) using wire nut (7). Connect the fixture ground wire (10) to the house ground wire (6) by fixed on the ceiling pan (3).
2. Carefully tuck all wiring back into the outlet box (1).
3. Attach the ceiling pan (3) to the outlet box (1) using the slotted holes on the ceiling pan (3) provided.
4. Place the shade (11) against the ceiling pan (3), and then rotate the shade clockwise until the shade (11) is fasten to the ceiling pan (3).
5. Installation complete, restore power at the circuit breaker and turn light switch on to activate this fixture.
6. This is integrated led fixture, no bulb to replace.



- | | |
|------------------------------|-------------------------|
| 1. OUTLET BOX (NOT INCLUDED) | 7. WIRE NUT |
| 2. MOUNTING SCREW | 8. WHITE FIXTURE WIRE |
| 3. CEILING PAN | 9. BLACK FIXTURE WIRE |
| 4. WHITE SUPPLY WIRE | 10. FIXTURE GROUND WIRE |
| 5. BLACK SUPPLY WIRE | 11. SHADE |
| 6. HOUSE GROUND WIRE | |