- Spring Arm

- Slides into vent frame

## INSTALLING SUPPORT SPRING CLIPS:

1. Slide Clips into the vent frame, into the 4 rectangular slots

2. Be sure to have the spring arm of the Clips on the **outside** of the frame NOTE: Clips may have sharp edges, handle with care or use a pair of needle nose pliers.

## IN THE CASE OF A LARGE ROUGH OPENING:

1. Bend the points away from each other to increase grip length using either fingers or needle nose pliers (as shown).

TOP/BOTTOM and SIDE VIEW of Clips on Vent Frame



Visit the following link to view an installation video, and click on the "Installation and Use Series":

## www.smartvent.com/media

NOTE: Clips do not need to be removed as they help hold the frame within the wall while the adhesive dries.

