








Step 9


	
M3. 5*14mm	H57mm
Ⓘ x16pcs	ⓙ x4pcs



Step 10


					
Ⓑ x2pcs	Ⓖ x1pc	M3. 5*14mm	128	M4*16mm	∅20mm
Ⓑ x2pcs	Ⓖ x1pc	Ⓘ x6pcs	Ⓛ x1pc	Ⓜ x2pcs	Ⓝ x2pcs






① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet





Step 11







M3. 5*14mm




① x8pcs



Step 12





Step 13




	
(K) x2pcs	(I) x10pcs


M3. 5*14mm

Step 14



2



				
(B) x2pcs	(I) x12pcs	(L) x1pc	(M) x2pcs	(N) x2pcs

M3. 5*14mm




128

M4*16mm

Ø20mm





Step 15

M3. 5*14mm	
Ⓚ x2pcs	Ⓢ x10pcs





Step 16

M3. 5*14mm	
Ⓐ x2pcs	Ⓢ x12pcs





Step 17



	 M3. 5*14mm
① x6pcs	① x6pcs

Step 18




N x26pcs

After installing the product, stick the number N on the perforated position