

ASSEMBLE INSTRUCTION

If you have any questions, please feel free to contact us.
Email: lowestteam@amazonlife.com




WF317848/WF317849/WF317850
Patio Sofa Set

- Notice:
- 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
 - Place the item on a flat ground to adjust and make sure it remains stable.
 - Tighten up all screws with tools gradually.
 - If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
 - If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
 - Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.


1-12

Exploded View




2-12

Part list and Hardware



3-12


Part list and Hardware



4-12

CARTON CONTENT


WF317848



5-12

CARTON CONTENT


WF317849



6-12

CARTON CONTENT


WF317850



Hardware


7-12

STEP 1




50%

STEP 2




50%

STEP 3




100%

STEP 4




50%

STEP 5




50%

STEP 6



100%

STEP 7



50%

STEP 8

50%

STEP 9

100%

STEP 10

50%

STEP 11

50%

STEP 12

100%

STEP 13

50%

STEP 14

50%

STEP 15

100%

12-12