





Product Name:	Wood and Metal Farmhouse Distressed Console Table
SKU #:	WHIF797

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.


PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

ID	Description	Qty	ID	Description	Qty
A	Tabletop 	1	B	Table Leg1 	4
C	Shelf 	1	D	Table Leg2 	4

Tools required for assembly: No tools are required for assembly.

STEP1




Product Name:	Wood and Metal Farmhouse Distressed Console Table
SKU #:	WHIF797

Assembly Instructions:

Place the tabletop upside down on a soft surface to avoid scratching the tabletop. Attach (B) legs to the bottom of the tabletop, as shown in the image above. Then insert the shelf into the bottom of the (B) legs, and screw on the (D) legs to firmly attach the shelf to the table legs. Be careful not to overtighten to avoid stripping the screws.

Gently turn the table upright. Give it a gentle shake to ensure that it is stable. Tighten legs as needed.

Enjoy your new console table!



WARNING: FOR YOUR SAFETY! To avoid injury and/or damage, please do not sit or stand on the table as this may cause serious bodily injuries and/or product damage.