



Item Number : F00009 - Dinning Set










Item Number : F00009/F00010 - DINNING TABLE



Read instruction carefully prior to assembly.

Thank you for purchasing this quality product. Check carefully for small parts which may come loose during shipment. Remove all components from pack and place top down on soft surface such as carpet or cloth to prevent scratching the finish. Identify and count all parts as specified below.




HARDWARE LIST

No.	Description	Sketch	Size	Q'ty
A	Allen Bolt		5/16"*65mm	8PCS
B	Spring Washer		5/16"	8PCS
C	Flat Washer		5/16"*19mm	8PCS
D	Allen Key		4mm	1PC
E	STRAIGHT ALLEN KEY		4mm x 4"L	1PC



PARTS LIST

No.	Description	Sketch	Q'ty
1	TABLE TOP		1PC
2	TABLE LEG		4PCS

STEP 1



Step 1: Turn Table top upside down and put on soft surface such as carpet or cloth and then take out MDF corner support on table top by using phillips screw driver (not included).




Item Number : F00009/F00010 - DINNING TABLE

Read instruction carefully prior to assembly.

Thank you for purchasing this quality product. Check carefully for small parts which may come loose during shipment. Remove all components from pack and place top down on soft surface such as carpet or cloth to prevent scratching the finish. Identify and count all parts as specified below.


STEP 2





Step 2: Turn table top upside down and put on soft surface such as carpet or cloth and then attach leg to corner using Flat washer (C), Spring Washer (B) and Allen Bolt (A). Using Allen key (D) and Tighten

Step 3: Turn table on upright position on level surface and tighten bolts

STEP 3





Item Number : F00009 -CHAIR

Read instructions carefully prior to assembly.









Thank you for purchasing this quality product. Check carefully for small parts which may come loose during shipment.

Remove all components from pack and place top down on soft surface such as carpet or cloth to prevent scratching the finish.




Identify and count all parts as specified below.

Note: need to be set on a level surface prior to tightening all the bolts. Once all the bolts and nuts are finger tightened, set chair on level surface to tighten bolts.


HARDWARE LIST

No.	Description	Sketch	Size	Q'ty
A	Allen Bolt		5/16"*35mm	18PCS
B	Allen Bolt		5/16"*75mm	24PCS
C	Lock Washer		5/16"	66PCS
D	Flat Washer		5/16"*19mm	66PCS
E	Hex Nut		5/16"*12 mm	24PCS
F	Allen Key		4mm	1PC
G	STRAIGHT ALLEN KEY		4mm x 4"L	1PC
H	Open wrench		12mm	1PC

PARTS LIST

No.	Description	Sketch	Q'ty
1	CHAIR BACK		6PCS
2	SEAT CUSHION		6PCS
3	FRONT LEG		12PCS


STEP 1



Step 1: Attach seat frame to chair back by securing the flat washer (D), Lock washer (C) and Allen Bolt (A) onto back rail.



Hand Tight only at this moment

STEP 2




Step 2: Attach seat frame to chair back by securing the flat washer (D), Lock washer (C) and Allen Bolt (B) onto back rail.

Hand Tight only at this moment




Item Number : F00009 -CHAIR

STEP 3



Step 3: Attach the front leg to the corner of the seat frame, tighten the front leg with flat washer(D),Lock washer(C) , and hex nut (E)

STEP 4



Step 4: Place Chair on flat surface and adjust legs so that chair is level and does not wobble, Tighten all the bolts with Allen Key(F) provided , Do not to over tighten.