


11x13 Dome Top Patio Gazebo

WE HAVE YOU IN MIND, LET US SERVE YOU!



Safety Information

Two people are required for this assembly.

Some parts may contain sharp edges.

Wear protective gloves.

When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

Please read all instructions before assembly and usage.



CAUTION: Do not climb on top of the gazebo. Falling off the gazebo can result in serious injury.

NOTICE: For outdoor use
















DANGER: This unit is heavy! Do not assemble this item alone
















WARNING: Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.




WARNING: Keep all flame and heat sources away from this gazebo fabric. This Gazebo is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.

Parts Name	Item No.	Parts Images	Qty.
Leg Post	A1		4
Short Side Beam C1	C1		2
Short Side Beam C2	C2		2
Long Side Beam D1	D1		2
Long Side Beam D2	D2		2
Long Top Bar	H1		2
Short Top Bar	I1		2
Upper Slant Bar	G1		4
Lower Slant Bar	G2		4
Top Connector	J		1
Long Netting Rod	E1		4
Short Netting Rod	E2		4
Long Extension Tube	K5		4

Parts Name	Item No.	Parts Images	Qty.
Short Extension Tube	K6		4
Big Canopy	O1		1
Small Canopy	O2		1
Netting	P1		4
Privacy Curtain	P2		4
Bolt DD	DD	 M6×20mm	32
Stake	II		8
Ring	LL		88
Top Decoration	M1		1
Support Tube	M2		1
Hook	N		1
Wrench	JJ		1
Sandbag			4




Hammer not included



Two person




1



Connect two Long Side Beams(D1) to Long Side Beams(D2) .


2

Connect Leg Post(A1) to assembled Long Side Beam(D1) by Bolt DD.




3

Connect Short Side Beams(C1/C2) to assembled Leg Post(A1) by Bolt DD.




4

Connect assembled Short Side Beams(C1/C2).




5



Screw the Support Tube (M2) on the Top Connector (J).


Attach the Hook (N) to the Top Connector (J).

6




Insert the Long Top Bar (H1) to the Top Connector (J).


Connect the Long Top Bar(H1) to the assembled Short Side Beams(C1/C2) and Short Netting Rod(E2) by Bolt DD.



7




Insert the Short Top Bar (I1) to the Top Connector (J).




Connect the Short Top Bar(I1) to the assembled Long Side Beams(D1/D2) and Long Netting Rod(E1) by Bolt DD.

8




Insert Lower Slant Bar(G2)to Upper Slant Bar(G1);

9




10



Put Big Canopy(O1) on big roof frame.


11

Attach the Short Extension Tube(K6) to Upper Slant Bar(G1).



Attach the Long Extension Tube(K5) to Bottom Lower Slant Bar(G2).

12




Put the Small Canopy (O2) on the assembled small roof (M2).

Screw the Top Decoration (M1) on the Roof Support Tube (M2).


To adjust the Short Extension Tube(K6) position to make sure the small canopy could be well fitted.

13



Firstly insert Top Bars(H1/I1) into side edge pocket on Big Canopy(01). Then insert Long Extension Tube(K5) into Big Canopy corner pocket, adjust the tube to suitable length.



14




Hang Netting(P1) on the inside of Netting Rod(E1/E2) by Rings(LL).

15

Hang Privacy Curtain(P2) on the outside of Netting Rod(E1/E2) by Rings(LL).




Fix gazebo Leg Post(A1) on the ground by Stakes(II).




Sandbag

①




Open the bag and fill it with sand or something else heavy.

②



Zip up the sandbag.

③




Place the sandbag next to the lower post.

④



Fix the bag to the leg by velcro.



Care and Maintenance

Our steel components for garden accessories and furniture are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur once these protective coatings are scratched. This is not a defect and thus not covered by the warranty.


To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, we recommend immediate touch-up with rust inhibiting paint.

Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.

Use damp cloth to wipe off the stains as quickly as possible.

If necessary, wash with a mild solution of soap and water; rinse thoroughly and dry completely.

Periodically check and ensure that all bolts are well-tighten during use



THE WIND SNOW WEATHER



Please remove the canopy in snowstorm and gale days to avoid unnecessary damage to the gazebo

Thanks so much for your purchasing, and hope you will have a pretty good experience both on assembly and daily using.

If any questions, please contact us