

LIMITED LIFETIME WARRANTY

Compass Manufacturing International warrants to the original consumer purchaser that the faucet be free from defects in material and workmanship for as long as the original consumer purchaser owns the home in which the faucet was first installed.

In the event that Freendo faucets are used in a Commercial Application, this warranty is limited for a period of 5 years, unless otherwise specifically stated in the catalog and/or price book.

Compass Manufacturing International will replace, free of charge, during the applicable warranty period, any part or finish that proves defective in material and/or workmanship under normal installation, use and service. This warranty shall not apply to goods which have been subject to accidents, negligence or improper installation. Compass Manufacturing International will not be liable for other damages or losses, including, but not limited to: labor charges and/or damages incurred in installation, repair or replacement as well as any other kind of loss or damage. Proof of purchase from the original consumer purchaser must be made available for all warranty claims.

Compass Manufacturing International recommends using a professional plumber for all installation and repair. Compass Manufacturing International will, at its discretion, provide replacement parts for installation by consumer for any parts that prove defective under normal usage and service with new or equivalent parts. Replacement parts may be obtained by emailing the address below, calling the number below or by writing to:

Compass Manufacturing International

Freendo Product Service 6702 Enterprise Drive Louisville, KY 40214 800.626.3525 warranty@cmiproduct.com

Revised 4/28/16

© Compass Manufacturing International

800.626.3525



Model No.: 192-5895 Polished Chrome

192-5896 Brushed Nickel **Spotless** PVD

192-5897 Oil-Rubbed Bronze



Two Handle Bar Faucet

2 Hole Installation, 4" Center-Set




Helpful Information

Helpful Tools

Tools:

Gather the necessary tools as shown below to complete the installation of this faucet. Some may not be needed depending on the model of faucet you are installing.




5

Parts List


23	Allen Key
22	Plastic Locknut
21	Washer
20	Putty Plate
19	Brazed Underbody
18	Cartridge(Hot Water)
17	Cartridge(Cold Water)
16	Deck Plate
15	Index (Blue)
14	Washer
13	Cartridge Locknut
12	Set Screw
11	Index (Red)
10	Handle
9	O-ring
8	O-ring
7	O-ring
6	Ring
5	Spout Nut
4	Aerator Collar
3	Aerator Core
2	Aerator Washer
1	Spout
No.	Part Name

Parts Diagram




1

Faucet Installation



1. Position the faucet, deck plate 16 and putty plate 20 on countertop as shown.


Faucet Installation



2. Put the washer 21 and plastic locknut 22 to tailpiece of faucet and tighten the plastic locknut by hand.

3

Configuration



Connect to water supply lines with either:

- (A) 3/8" O.D. Copper tubing (ball nose risers with the coupling nuts or;
- (B) 3/8" Copper tubing (no ball) with supplied tube head interior connector or;
- (C) IPS faucet connectors (½")



Warning:

The supply valves and supply lines are not included.



Important:

Remove the aerator and let both hot and cold water run for one minute to clear any line trash. This will help clean any debris that might clog the system. Re-assemble aerator.

Test system for leaks.