

ASSEMBLY INSTRUCTIONS


MODEL

EC7866-F

Questions?


GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver (Not included)



Allen Wrench



2 - People

ASSEMBLY RATING











- D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com









foagroup



Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BED

.....



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.




PARTS

















HEADBOARD

HB - LEG LEFT

HB - LEG RIGHT

FOOTBOARD





















FB - LEG RIGHT FB - LEG LEFT

SIDE RAIL

SLAT 1540 x 42 x 17mm

VERTICAL LEG 200 x 29 x 29mm

HARDWARE

HARDWARE INSIDE HEADBOARD / FOOTBOARD



















Flat Washer (Small)



Flat Washer (Big)



Allen Key M4



Bolt M6x35mm

Lock Washer

Wood Button

HARDWARE INSIDE SIDE RAIL

G 6pcs



Panhead Screw M4x30mm

EC7866-F-3A is packed in 2 cartons

CARTON	DESCRIPTION	PART	HARDWARE
EC7866-F-HBFB-3A	FULL HEADBOARD	① 🕡 ×1	A x 12 PCS B x 12 PCS
	FULL HB - LEG LEFT	② = x1	© C x 4 PCSO D x 8 PCS
	FULL HB - LEG RIGHT	③ <u>×</u> 1	Ex1PC Fx4PCS
	FULL FOOTBOARD	4 x1	V 1 × 11 00
	FULL FB - LEG LEFT	⑤ ☞ x1	
	FULL FB - LEG RIGHT	⑥ ← ×1	
EC7866-F-R-3A	FULL SIDE RAIL	7 ×2	G x 6 PCS
	FULL SLAT	8 x3	
	FULL VERTICAL		

ASSEMBLY INSTRUCTIONS

1

Part 1 1pc

Part 2 1pc

Part 3 1pc

Part 4 1pc

Part 5 1pc

Part 6 1pc


Hardware A 8pcs

Hardware ® 8pcs

Hardware

8pcs

Hardware € 1pc



by using bolt (#A) with lock washer (#B)

and flat washer (#D).

2


Hardware A 4pcs

Hardware B 4pcs


Hardware C 4pcs

Hardware (E) 1pc

Hardware F 4pcs



ASSEMBLY INSTRUCTIONS



This product is intended for RESIDENTIAL USE ONLY and not commercial use.