



To deodorize the leather,
leave the chair in a shady
outdoor area for 1-2 days.



For longer use

Re-tighten bolts every 6 months by using
the enclosed Allen-key.

*Using an electric drill can damage the chair.
Please re-tighten the bolts manually.



Safety Information



Sit in the center of the
chair, with your back against
the backrest



Do not sit on the front
edge of the chair



Do not stand on the
chair



Do not use the chair
with more than one
person



Do not push the chair
around when a person
is sitting in it



Do not push down on
the backrest when a
person is reclined



Do not place your
entire weight on the
backrest



INSTRUCTION MANUAL

C-7295L


Package List




(A)*1



(B)*1



(C)*1



(D)*1



(E)*1




(F)*5



(G)*5



(H)*5



(I)*1



(J)*5
M6*18mm



(K)*4
M6*20mm



(L)*4
M6*30mm




(M)*4
M6*25mm




(N)*1

Assembly Instruction




1




2

NOTE:
Choose either (G) or (H) to install. The following illustration uses (G) as an example for installation.




3







4

Instructions For Use



5



CAUTION:

- * Before using the chair, check to ensure that all bolts are fully tightened.
- * Lubricate all parts and tighten all bolts every 6 months or whenever needed.