



1080 Bassett Road, Unit D
Westlake, Ohio 44145
(866)740-0005
support@EZSnapCovers.com

How To Install EZ Snap Covers:



Scan code for
Instructional Video

1. Remove the existing endcaps
2. Now, remove the front cover
3. Then remove the damper but keep the back plate attached to the wall. These pieces are metal. We recommend that you Recycle.
4. The next step is to test fit your EZ Snap™ Covers onto your existing wall plate and snap into place.
5. After confirming it fits, pull your EZ Snap™ Covers off the wall plate and slide the endcaps onto your EZ Snap™ Cover. The whole unit may now be snapped into place. Adjust or pull the endcaps to meet the existing baseboards or wall.
6. To install the couplers, hook the bottom of your EZ Snap™ Covers and then snap it up and over, into the gap between the wall and the cover.

All baseboard heaters are not exactly the same. Some adjustments may be needed to make them fit properly. Many covers have been attached to walls for 40 – 50 years. They have been bent, painted, caulked, and houses settle. Sometimes you may have to not play nice with them to make them fit properly.