




MANHATTAN
COMFORT

ASSEMBLY GUIDE

SB-313AMC






STOP!


Before beginning the assembly process, ensure all boxes and parts have been delivered.

FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



TOOLS REQUIRED



SUPPORT SITE



View our assembly video online:
WWW.MANHATTANCOMFORT.COM





Stuck? Question? We are here to help.
tel: **1-908-888-0818**
e-mail: help@manhattancomfort.com




Included in this package:

- 01. Base x1
- 02. Top x1
- 03. Left Side x1
- 04. Right Side x1
- 05. Division x1
- 06. Shelf x2
- 07. Top Shelf x2
- 08. Door Left x1
- 09. Door Right x1
- 10. Back x2
- 11. Wood Feet x4



Included in this package:

A- 
EF 000033 x 16


B- 
EF 000094 X 10

C- 
EF 000216 X 14

D- 
EF 000106 X 20

E- 
EF 000132 x 6


F- 
EF 000168 X 30

G- 
EF 000043 X 4

H- 
EF 000025 X 4

I- 
EF 000745 x 4

J- 
EF 000741 x 1


K- 
EF 000008 x 1


P- 
PLASTIC SUPPORT X 8


Q- 
EF 000731 X 2

R- 
EF 000067 X 2

Y- 
CHALK x 01

Z- 
STICKER x 24



L- 
PUSH OPEN x 02

M- 



N- 

A = 16 KG - 35.5LB


B = 3KG - 6.61LB






1






2

-  A- x8
-  D- x8
-  H- x4
-  P- x4
-  B- x4






3



-  A- x8
-  P- x4






4

-  D- x8
-  G- x4










5






6





NOTE:
NOTA:






7





NOTE:
NOTA:





8








9




10










-  L- x2
-  M- x2
-  N- x2
-  D- x4



To attach "push open" system, fix part L using hardware D, fit part M, put part N on the magnet, remove the tape film and close the door.







MANHATTAN
COMFORT

WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the



319 Ridge Rd. Dayton, NJ 08810
908-888-0818